NEWGATE

"PIL"

NEWGATE

Features

Designer LED clock with bright display

Alarm and Snooze

12/24 hour format

Night screen brightness setting

Temperature 0-50°C

Enclosed USB power cable connects to your USB plug for bright screen illumination

Requires 3 x AAA battery to retain clock functionality during power outages (not included)

Contents

1 x LED Pil Clock

1 x USB Cable

1 x Features & Instructions booklet

DOWN

UP

SNOOZE

ALARM

MODE

Screen shows time
in 12hour or 24hour
format

Alarm
icon

Room
Temperature

USB Cable Input

Battery
Compartment

Battery Installation

Remove the battery compartment cover and insert 3 x AAA batteries (not included)

Make sure the batteries are inserted the correct way around according to the markings.

Never mix new and old batteries.

Never mix alkaline, standard (carbon-zinc) or rechargeable batteries.

Use a standard USB phone charger (5V, 2A) to power your clock using the supplied USB cable.

Setting the Time

Press MODE for 2 seconds for time setting mode.

The sequence for setting the time is HOUR, MINUTE, 12/24 HOUR.

Press UP and DOWN to adjust the digit. Hold UP and DOWN for more than 2 seconds to adjust the digit faster.

Press MODE to move to the next setting.
Once all settings are correct, Press MODE to confirm and exit the time setting mode.

The time setting mode will confirm and exit automatically after 10 seconds of inactivity.

Other Settings

Hold MODE for 2 seconds for time setting mode.

Press UP to select the brightness HIGH > LOW.

Press MODE once to view the temperature. When in temperature display mode, press DOWN to switch between centigrade and fahrenheit. Press MODE for 2 seconds to cycle the display between temperature and the time.

The display only works continually when a DC adaptor/USB cable is connected.

Batteries must be installed to ensure the time is stored and not lost during a power outage.

When using batteries only, press any button to light the screen for 10 seconds. The light switches off after 10 seconds to preserve your battery when the USB cable is not connected.

Setting the Alarm

Press ALARM once to turn it on/off. When the alarm is on, the Alarm icon 🔔 will be displayed on the LED screen.

Press ALARM for 2 seconds for alarm setting mode. The sequence for setting the alarm is HOUR, MINUTE, SNOOZE duration. The default Alarm time is 6:00am. The SNOOZE duration can be set between 5-60 minutes.

Press UP and DOWN to adjust the digit. Hold UP and DOWN for more than 2 seconds to adjust the digit faster.

Press ALARM to move to the next setting.

Once the time is correct, press ALARM to confirm and exit the alarm setting mode.

When the alarm is triggered, the Alarm icon 🔔 will flash and the buzzer will sound for one minute.

Press ALARM to turn the alarm off. The alarm will turn off automatically if it is not snoozed or cancelled within one minute and will repeat the alarm the next day.

When the alarm is sounding, press SNOOZE to snooze the alarm for the pre-set snooze duration (default snooze duration is 5 minutes). If the snooze is active the Alarm Icon 🔔 will flash. To cancel snooze before the pre-set time is up press any button other than SNOOZE.

Temperature Function

Press MODE once to switch to temperature display mode.

The temperature display will show room temperature between 0-50°C (32-122°F).

To change the temperature unit, when in temperature display mode, press DOWN to switch between °C and °F.

Backlight Level Settings

If the clock is powered by batteries only, press any button to activate the display for 10 seconds.

When connected to DC adapter/USB cable the display will always be on. Press UP to select the display brightness level. The sequence for setting the brightness level is HIGH > LOW.

Night Mode Setting

When active, night mode will automatically dim the display from HIGH brightness to LOW during specified hours. The default hours are between 6pm and 6am. Night mode can be overridden at any time using the UP button.

If the clock is powered from the batteries only, night mode will not function.

Press MODE twice to see if the night mode is set to ON or OFF.

When in night mode setting press UP or DOWN to switch night mode ON or OFF.

If night mode is on, Hold MODE for 2 Seconds to adjust night mode setting. The setting sequence is START HOUR, START MINUTE, END HOUR, END MINUTE.

Press UP and DOWN to adjust the digit. Hold UP and DOWN for more than 2 seconds to adjust the digit faster.

Press MODE to move to the next setting.

Once the night mode time is correct, press MODE to confirm and exit.

The night setting mode will confirm and exit automatically after 10 seconds of inactivity.

Maintenance

When cleaning, we recommend a light dusting with a soft, clean and dry cloth only. The use of liquids and cleaning agents may damage the finish of your clock.

Please keep your clock out of direct sunlight to protect it from harmful UV rays that may discolour the screen or case. This clock is for indoor use only.

Guarantee

Should you experience any difficulties with your clock it is guaranteed for two years from the date it was purchased. For assistance please contact the store it was bought from along with your receipt, or contact us at hello@newgateworld.com

About Us

British clock brand Newgate is famous the world over for their iconic analogue and LED clocks, collected by people who appreciate individuality, design and style.

Newgate's LED clocks are built with a passion for electronic engineering and design, delivering a fusion of cool functionality and crisp bright clock screens that not only tell the time, but wake you up and tell you the temperature in the room.

Contact Us

Email: hello@newgateworld.com
Web: www.newgateworld.com
Instagram: @newgateworld

Newgate World   Factory 3
Glovers Meadow   Oswestry
Shropshire   SY10 8NH
United Kindgom

EU A/R: Comply Express Lda,
StartUp Madeira - EV 141 -
Campus da Penteada,
9020 105 Funchal