

6-OUTLETS MECHANICAL TIMER YARD STAKE

Features

- 24-hour push-pin mechanical timer
- 6 outlets

Setup

1. Set a period of time for the timer to be "ON"
 - Locate the gray pins and push them DOWN at the marked times when the attached device is to be "ON" .
 - Each pin represents a 30 minute time interval.
2. Set "CURRENT TIME"
 - Rotate the entire gray push-pin dial clockwise until the arrow marked "CURRENT TIME" aligns with the current time of day on the dial.
 - "AM" hours are highlighted in WHITE. "PM" hours are highlighted in BLACK.

3. Plug YARD STAKE into an ELECTRICAL OUTLET
 - Use up to 6 DEVICES to the YARD STAKE
 - Plug the device into the outlet on the side of the YARD STAKE.

HELPFUL TIPS

- This timer YARD STAKE repeats the same settings daily.
- To push down or pull up the gray pins, use your finger or the tip of a small non-metallic insulated tool, such as a pencil or toothpick.
- Set up to 48 different "ON" and "OFF" times in a 24 hour period by the positioning of the gray pins. Pins pressed down represent the 'ON' time. Pins in the up position represent 'OFF' time.
- Once the YARD STAKE is set on the ground, it will sit at a slight upward angle making it easier to read and program the unit.

IN CASE OF POWER FAILURE

- Timer will stop operating if the power goes out. Once power is restored, reset the time of day as explained in Step 2 of the instructions.

SAFETY INFORMATION & SPECIFICATIONS

- THIS YARD STAKE IS FOR USE WITH A 125 VAC POWER SOURCE.
- 125VAC / 60Hz

DO NOT ATTACH A DEVICE THAT EXCEEDS THE UNIT RATINGS:

- 15A / 1875W Resistive (General Purpose)
- 8A / 1000W Tungsten (Incandescent)
- 1/2 HP (Horsepower Motor)

WARNING: RISK OF ELECTRIC SHOCK

- Keep children away
- Unplug timer before cleaning
- Fully insert plug
- Do not use near standing water.

RISK OF FIRE

- Do not use to control appliances that contain heating elements (cooking appliances, heaters, irons, etc.)
- Do not exceed electrical ratings.

BN-LINK INC.

12991 Leffingwell Avenue, Santa Fe Springs
Customer Service Assistance: 1.909.592.1881
E-mail: support@bn-link.com
[Http://www.bn-link.com](http://www.bn-link.com)
Hours: 9AM - 5PM PST, Mon - Fri
Designed in California Made in China