

8264-1901 Rumba Fountain (2 pieces)

COMPONENTS AND PARTS LIST



Water Feature
12"W x 1"H
10 lbs

Basin
17"W x 18"H
65 lbs

Fountain holds
approximately 10-15
gallons of water

Pump Kit Parts List

PK300 pump (1)
6" length of 1/2" Black Non-kink tubing (1) *
18" length of 1/2" Black Non-kink tubing (1)*
2" length of 5/8" clear tubing (3)*
Valve (1)*
Wedges (4)
Hose clamps (1)

* Tubing has been preassembled

This fountain is compatible with a
#10 or #7 Refill Device

Tools you will need

Level



This fountain takes cover
FTNCOV-SM

8264-1901 Rumba Fountain (2 pieces)

ASSEMBLY INSTRUCTIONS

1. Make sure you are assembling your fountain on a level surface
2. Assemble the pump kit
 - a. **NOTE: Be sure to use the appropriate size adapter provided with the pump.**
 - b. Using a hose clamp, secure the 6" length of the 1/2" black tubing of the tubing assembly to the pump.
3. Remove the cap covering the standpipe.
4. Feed the pump cord through the standpipe in the basin, leaving enough cord length inside of the basin to work with the pump sitting flat in the bottom of the bowl.
5. Replace the cap to cover the standpipe and cord.
6. Slide the 3" length of 5/8" clear tubing of the tubing assembly onto the copper pipe extending down from the bottom of the water feature
7. Place the water feature on top of the basin making sure that the water feature is level.
 - a. Note – Wedges may be used if necessary to level the water feature.
 - b. Note – Do not allow pump to run dry, as it will cause damage to the pump

WINTER CARE AND GENERAL FOUNTAIN INSTRUCTIONS

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with a breathable, lightly colored material (fountain covers sold by Campania International are recommended), making sure that water will not accumulate in the basin or other fountain component and freeze.
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

For more Campania product information visit www.campaniainternational.com