

100 mm

70 mm

### Attention

- Improper use may result in product damage, decreased battery life and loss of charging capacity not covered by the manufactures warranty.
- Check device voltage for compatibility before use.
- Only charge the unit from your computer or a certified approved power adaptor. (certification depends on your region)
- Do not store this power bank in high or low temperature environments, small enclosed areas without ventilation or place in fire.
- Do not drop, bump, throw or shake the unit, this may damage internal components.
- Do not disassemble or try to repair or modify.
- If battery becomes excessively hot, emits odour, gets dented or experiences any abnormal deformity you should stop using it immediately.
- Only dispose of battery at authorized recycling centre.
- Do not use harsh chemicals or cleaning agents on the exterior of this unit.
- Do not touch the light directly when the light works for a long time.
- Do not put the product in water, IP65 waterproof resistant with two covers will be sealed.
- Do not place the product in a place easily accessible to children.
- Do not stare at LED light directly, it will hurt your eyes.

### FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and.
- (2) this device must accept any interference received, including interference that may cause undesired operation.




We reserve the right to explain the terms of this product.

## 2 IN 1 LED Flood Work Light Power Bank 10000mAh


### LP10

### User Manual

Portable warm/Warm white/daylight white LED Flood work light, 15 LED modes, IPX4 waterproof resistant for Home, Garden, Outdoor, Hiking, Fishing, Emergency, Fill Light and more.  
10000mAh rechargeable Battery Pack for charging your smartphone, tablets and more USB devices.



### Indicator

- (1) To check the power level, short press the Power Button  , the Blue LED Power Level Indicators will light up:  
None Blue LED on means 0%;  
One Blue LED on means 1~ 25%;  
Two Blue LEDs on means 25~50%;  
Three Blue LEDs on means 50~75%;  
Four Blue LEDs on means 75~100%.
- (2) Charging: one of these 4 Blue LEDs flash, when full of battery, the 4 Blue LEDs will light. LED display is flashing with showing Power bank current Power level.
- (3) Discharging: Blue LED light to show power bank current power level.

### Specifications

Battery Type: Li-ion battery  
Capacity: 10000mAh @ 3.6V (36Wh)  
Input: DC 5V 2A Max  
Output: DC 5V 2A Max

#### Daylight White LED

- Power 7.2W max
- LED Chromaticity Coordinates: 5500-6000K

#### Warm LED

- Power 7.2W max
- LED Chromaticity Coordinates: 3000-3500K

#### LED Mode

- Daylight White: 100%/60%/30%/3%/SOS
- Warm: 100%/60%/30%/3%/SOS
- Warm White: 100%/60%/30%/3%/SOS

Dimension: 115.5x120.5x42.5 mm / 4.55x4.74x1.67 inches  
Weight: 330g  
Operating Temperature: 0~40°C

### How to Use

#### Charging the Power Bank:






- The unit should be recharged every 3 months when not in use.
- Insert the regular USB end into the output USB jack of computer or wall outlet adaptor.
- Insert the Micro USB end into the input port on the power bank.
- The indicator is flashing showing it is charging.
- The 4 Blue LEDs show Light Once fully charged.

#### Charging Your Devices:

Please note: Always check the voltage compatibility of your device before connecting to the power bank.

- Insert your device's regular USB charging cable into the output port of power bank.
- Insert the other end into your electronic device.
- Your device should indicate that charging has started.
- The Blue LEDs decreasing one by one showing the power bank is discharging.
- When you are finished with charging please remove the USB cable from the power bank.

### Different Mode of LED light:


- Press the Power Button  , the LED Indicator will be turned on, check the power level.
- Long Press the Button  about 2 seconds, the flood work light will be on and be at the 100% daylight white color;
- Press the Button  to toggle from Daylight White/Warm/White & Warm 3 colors, Press the Button  or  to change 100%/60%/30%/3%/SOS 5 modes.

#### Graphic operation:



### Placement mode:

- Press and Hold side button to adjust the metal kickstand angle, totally 4 different angles (0-90 degree).
- Hang the unit where you need it by attaching an iron pothook.
- Fix it into your tripod (not included) via the hole on stand, the screw specification of the hole is M6, make sure your tripod matches the product before use.



### Package Details

10000mAh Rechargeable Flood Work Light Power Bank x1  
Micro USB Cable x1  
User Manual x1