Exit Devices

Accessories

Various replacement and accessories for our exit device range.











MX002

Plastic alternative to glass for CP15 and CP21 range.

CP-GLASS-N

Replacement clear glass for CP15, CP21, CP15N and CP21N.

MX003-N

Clear plastic cover for CP15, CP21, CP22, CP15N, CP22N, CP22-3N, CP21N and CP22N-EDR.

CP24-G-COVER

Clear plastic cover for CP24G.

CP31G-UC-COVER

Clear plastic cover for CP31G-UC.









Clear plastic cover for CP32-G-L.

PS200

Clear plastic cover for CP22-3WP.

MCP110-COVER

Clear plastic cover for MCP-110.

DRB-SH

Stainless Steel Surface Housing. Availabel with red, green, white and brass finishes. Silver available with backbox.









DRB-SH-N

Narrow Stainless Steel Surface Housing

DRB-SH-B

Narrow Brass Surface Housing

CP22-3 KEY

Black plastic key for CP22-3.

CP22-KEY

Black plastic key for CP22

CP22-KEY-N

Black plastic key for CP15, CP15-N, CP21, CP21-N, CP22-N and CP22N-EDR.



BG1 KEY

Black plastic key for BG1 and BG1G.



CP31G-UC-KEY

Orange plastic key for CP31G-UC.



CP32-G-L-KEY

Clear plastic key for CP-32-G-L.



MCP110-KEY

Clear plastic key for MCP-110.