





INSTRUCTIONS: COAST EAL18 PORTABLE AREA LIGHT

USING THE AREA LIGHT

Use the Power Button to turn on your EAL18, as well as cycle through all four lighting modes—low, high, red, and flashing red.

POWERING THE AREA LIGHT

The EAL18 was designed on COAST'S Dual Power platform and can be powered by four COAST D-cell INDUSTRIAL PERFORMANCE™ alkaline batteries or a COAST ZITHION-X™ rechargeable battery (not included). To change the batteries, twist the base of the area light counterclockwise and remove the base-cap to expose the battery compartment. Remove the old batteries, discard, and install all new batteries. COAST INDUSTRIAL PERFORMANCE™ alkaline batteries can be purchased separately on coastportland.com.

Note: Do not mix old and new batteries.

UPGRADING TO RECHARGEABLE POWER

To purchase a ZITHION-XTM rechargeable battery that is compatible with your EAL18, visit COASTportland.com/DP.

HANGING THE AREA LIGHT

The EAL18 was designed with an integrated folding handle and built-in lantern hook for hanging. Before hanging the area light, be sure the folding lantern hook has snapped into place in the upright position.

CLEANING THE AREA LIGHT

Use a damp cloth to wipe down the body of the area light.

Caution: Never submerge the EAL18 in any liquid.

WARRANTY

The EAL18 is protected by a COAST 5 Year Warranty. For expedited warranty service, as well as discounts and exclusive access to other COAST products, join the COAST Crew at coastportland.com/join.

- FOUR LIGHT MODES
- FOLDING LANTERN HOOK
- FOLDING HANDLE
- 4 POWER BUTTON
- TWIST OFF BASE-CAP / BATTERY COMPARTMENT
- 4 X D COAST ALKALINE BATTERIES (NOT INCLUDED)
- ZITHION-X™ RECHARGEABLE BATTERY (NOT INCLUDED)

