COAST G450

FLASHLIGHT

1 11/1/22

INSTRUCTIONS: COAST G450 FLASHLIGHT

LIGHT SETTINGS

To turn on the G450, click the power button on the tail cap. The light will start on the Medium light mode, then cycle to High, and finally to Low. To cycle from one light mode to the next, quickly click the power button two times.

The G450 is also equipped with Coast's Quick-Cycle™ technology. Lightly pulse the power button to preview each mode. Fully click the power button once you've found your desired mode to select it. A single click of the power button from any mode will turn off the light.

FOCUSING

To adjust from Ultra-View Flood beam to Bulls-Eye™ Spot beam, twist the bezel clockwise.

The G450 is powered by six COAST Extreme Performance AA Alkaline Batteries. To replace the batteries, unscrew the tailcap of the flashlight and remove the battery cartridge from the battery compartment. Remove the old batteries from the battery cartridge, discard them, and refill the battery cartridge with six new AA batteries, Return the battery cartridge to the battery compartment, with the arrow pointed toward the bezel of the flashlight.

Do not mix old and new batteries. COAST Extreme Performance Alkaline Batteries can be purchased at coastportland.com/ep

MAINTENANCE

To clean your G450, wipe the external body of the flashlight with a damp cloth. Note: Do not submerge the G450

At COAST, we stand behind everything we make. For warranty information specific to your country, please visit www.coastportland.com/warranty

JOIN THE COAST CREW:

- Expidited warranty service
- Earn points towards discounts off your next purchase
- Exclusive access to promotions and new product releases

GO TO COASTPORTLAND.COM/JOIN TO SIGN UP



22-787v01E 2210A

QUESTIONS? 877-704-4545

COASTPORTLAND.COM



