



COAST®



COAST PX20 FLASHLIGHT

INSTRUCTIONS

BATTERY INSTALLATION

Turn the head of the light in a counter-clockwise direction to remove from the body of the light. Remove the battery cartridge. Place three AAA batteries into the cartridge in the direction indicated on the cartridge. Replace the cartridge in the light. Replace the tail cap and turn it clockwise to tighten it until it is completely closed.

Note: The PX20 in packaging comes with the batteries pre-installed.

ON/OFF OPERATION


The PX20 has separate switches for each of the two colors. To activate the white light, press the gray or black switch, depending on the body color of the light. This switch is textured to allow identification in the dark. To activate the red light, press the red switch.

MAINTENANCE

Wipe the external body with a cloth moistened with water or isopropyl alcohol. Do not submerge.

WARRANTY

For warranty info visit: www.coastportland.com



INCLUDED:

