




# ULTRA PAWS DOG BOOT GENERAL SIZE CHART

BASED ON THE WIDTH OF THE PAW



1 in	1.25 in	1.5 in	1.75 in	2.25 in	2.75 in	3.25 in	4 in
XX-Petite	X-Petite	Petite	X-Small	Small	Medium	Large	X-Large
2.5 cm	3.2 cm	3.8 cm	4.5 cm	5.7 cm	7 cm	8.3 cm	10.2 cm

\*Sizing differs for Ultra Paws Cozy Paws®, Pawtector Warterproof, and Wound Boots products. Please check our website for product specific sizing.



## HOW TO MEASURE

- Place sheet of paper on a firm surface.
- Put your dog's front paw on the pawprint above, making sure the paw is in the middle.
- Lift your dog's opposite paw so that weight is placed firmly onto the paw being measured.
- Mark both sides of the weighted paw at its widest point on the sheet of paper.
- Measure the distance between both marks and compare to the boot sizes listed above.
- Choose the size that works best for your dog.

\*The width of the paw should be smaller than the boot size.

(For example, if the foot width is 1.5 inches, order an X-Small at 1.8 inches.)

**NOTE:** When printing this document make sure your printer is set to print **ACTUAL SIZE**