

CO₂ STORAGE SAFETY STROBE TOWER

Keeping You On High Alert

This strobe tower provides a bright, flashing indicator and alarm sound for any of our CO₂ or Oxygen Storage Safety Alarms. It clearly indicates the alarm level to anyone in the room.

The tower strobe colored lights are used as follows:

- **Green** - Normal air
- **Clear** - Alarm level 1 / Relay 1 triggered.
- **Amber** - Alarm level 2 / Relay 2 triggered.
- **Red** - Alarm level 3 / Relay 3 triggered.

The strobe tower is controlled by the relay outputs on the RAD sensor unit (SEU).

Features

- CM-1026-5 - 16" CO₂ Storage Safety Strobe Tower with 100-240AC electrical, requires user supplied power plug.
- Requires 110VAC to 240VAC power source and connections.
- May require additional wire to remote mount the strobe tower.
- Uses "Alarm/Relay" connections on the back of the RAD-0102-6 to activate strobes/horn.
- See attached wiring diagram: Connecting the CM-1026-5 Strobe Tower

Specifications

- 6 Ft (2m) Cable included
- Length: CM-1026-5 16"
CM-1026-6 11.5"
- Diameter: each 1.5"
- Alarms set to match 3 relays on RAD units (user configurable)
- Mounting bracket included

Works With

- **RAD-0102-6** | Remote CO₂ Storage Safety 3 Alarm Remote
- **RAD-0012** | Oxygen Enrichment Safety Alarm
- **RAD-0002** | Remote Oxygen Storage Safety Alarm