


# QUICKSTART GUIDE

## AS-TOGO SERIES PORTABLE RECHARGEABLE BLUETOOTH LOUDSPEAKERS




### CONNECT A MICROPHONE


Select Mic



Connect your microphone




Turn volume knob to adjust mic level




### CONNECT A LINE SOURCE


Locate the Line input (either RCA or 3.5mm TRS)



Connect your external source to speaker (RCA shown)




Turn volume knob to adjust input level




### CONNECT A BLUETOOTH DEVICE


Press MODE button until BT appears



Turn BLUETOOTH on and select AS-TOGO speaker on your mobile device



Play music from your mobile device




# QUICKSTART GUIDE

## AS-TOGO SERIES PORTABLE RECHARGEABLE BLUETOOTH LOUDSPEAKERS




### USING THE RADIO


Press MODE until FM appears



Press and hold the PLAY button to begin scanning for stations




Use the I<< and >>I buttons to select from available presets




### CHARGING THE BATTERY


Connect the speaker to power to charge



Charge the speaker when it reaches 25% remaining




When charge reaches 100%, unplug the speaker from main power



### USING THE RETRACTABLE HANDLE

To extend the handle, press the button in the middle of the handle and pull



The handle will lock in 2 positions. Use the one most comfortable to you



To retract the handle, press the button and push the handle down until in the recessed position

