

R0 ILLUMINATION / WARNING / SIDE MARKER MODULE

WIRING:

To +VDC(fuse rating @ 0.5A):**RED**

To Vehicle Chassis Ground:**BLACK**


(For steady-burn models, external flasher may be used for warning purpose.)

INSTALLATION:


(Actual mounting kit will be based on the ordered model)

Surface mount

Standard Flange



45° Angled Flange



INSTRUCTION:

1. Place the lighthouse on to the selected surface and mark the two screws mounting position.
2. Drill a wire access cut-out (suggested diameter @ 0.23" [6.0mm]) on the selected mounting surface between the two screw marks.
3. Lead the wires through the foam pad and the cut-out.
4. Make all necessary connections.
5. Align mounting holes with the foam pad and tighten both screws.