

Tenor




Apply brake




Control handset




System failure lower override




Loop sling attachment




Release brake



Dual control switch



Emergency stop button



Cleaning and disinfection

For cleaning, wipe down with a damp cloth using warm water and a mild detergent.

For disinfection, rub the product completely with "hard surface disinfectant wipes" impregnated with a mild detergent.

