



PLEASE NOTE

THE GLASS-CHEK ASSUMES
THE GLASS IT IS CONTACTING IS SURFACE 1.
THE ILLUSTRATION BELOW SHOWS WHAT THE
METER WILL CALL EACH SURFACE.



SURFACE 1 = SURFACE TOUCHED BY METER