



# E014S EXCEL-SINK HAND REMOVABLE PULL OUT BASKET


1. Fix the runner according to the diagram shown



2. Fix the main frame with screws



3. Hang the basket as shown



4. Ensure that the unit runs smoothly

