



START HERE



- 5 quick steps to setup your TWINS -

Step 1. Turn on both speakers

Step 2. Set one speaker to 'Master' by pressing the TWS button once
- A searching sound will play.

Step 3. Press the same TWS button again
- Wait a few seconds, a confirmation chime will play. Ready to connect to your device.

Step 4. Select "TECH-LIFE TWINS" in your device's Bluetooth settings
- A new confirmation chime will play once connected.

Step 5. Enjoy!

Note: Once connected, the TWIN with **green** & **blue** LED lights indicates the Left Channel.



PRO TIPS

1) Pairing TWINS to a different device

- a. Hold down the BT button on either speaker, the TWIN will enter pairing mode, make a sound, and flash its LED, the speaker will now be discoverable in your Bluetooth settings. Hit 'Scan' on device if the TWINS aren't on the device list.

2) Using TWINS independently with different devices:

- a. Hold TWS button on either speaker until you hear the 'Bluetooth searching' sound. Then connect to media device. Now each speaker will have separate inputs and outputs.
- b. To re-connect the TWINS together, hold down the TWS button on the new master speaker, the 'Bluetooth searching' sound will play, followed by 'twin pairing' confirmation sound. Next, turn the speakers off and then back on, they will now be reconnected for stereo playback.

3) A "low battery" sound will play when the twins reach 10% battery

4) To save power, TWINS will automatically power off after 15mins without being connected to a device.

5) Connect TWINS via 3.5mm cable for analog playback through a headphone jack.

Note: Twin pairing will be disabled in this mode.

6) Connect TWINS to a computer via USB cable to play audio from your computer or media device.

Note: Twin pairing will be disabled in this mode.

7) Charging Indicator next to USB Port: Red Light ON = Charging / Light OFF = Battery Full.

8) Double tapping the BT button will initiate a call with the last contact your device held a call with



1 YEAR LIMITED WARRANTY AGAINST MANUFACTURING DEFECTS
WARRANTY DOES NOT COVER UNITS THAT HAVE BEEN SUBMERGED IN WATER OR ANY OTHER FLUID

www.tech-life.com



1) **BT** BT/Media Connect

2) **TWS** TWIN Pairing

3) **Power** Power Switch

4) **+ -** Volume Keys

5) **LED** Connection Status LED Indicator
 Blue + Green = Left channel Blue only = Right Channel



6) **Micro USB***
 For charging the battery via any USB port and playback on most computers.

7) **Aux Input***
 The 3.5mm socket is for AUX playback.

8) **Mounting Receptacle**
 For mounting to any 1/4inch threaded camera mount or tripod.

9) **Charging Indicator**
 When plugged in: **Light ON = Charging**
Light OFF = Battery Full

For Start-up Guide & Pro-Tips
SEE REVERSE

>Visit www.Tech-Life.com for Twin Mounts seen here