

# Download the SAKI Smart App



To download the SAKI Smart App, scan the QR code or search "SAKI Smart" in the Apple App Store or Google Play Store.

## Smart Functions

Remote Control

SAKI Chef Recipes

Monitor Cooking

Voice Control

Custom Cooking Menus

## Setting Up Your Air Fryer



### 1 Plug-In

Plug-in your air fryer. Do not press to power button yet.



### 2 Sleep Mode

Make sure that your air fryer is in sleeping mode. When the air fryer is on sleep mode, only the orange power button will light up.



### 3 Long Press

Press on to the orange power button for 5 seconds. Then your device will make a beep sound and the WIFI indicator begin flashing rapidly on the screen.



### 4 Rapid Flash

Make sure that the WIFI indicator icon flashes rapidly. If the indicator flashes slowly. Press the power button again for 5 seconds.



### 5 SAKI Smart App


Go on to the SAKI Smart App and follow in-app instructions on the next page.

## Setting Up Your Air Fryer

To get the maximum benefit from your air fryer, we highly recommend using the SAKI Smart app. Please follow the steps stated below to connect your air fryer to your mobile device.

**Step 1:** Open the SAKI Smart App. If you already have an account, tap login. To create a new account, hit the Sign Up.

**Note:** You must create your own SAKI Smart account to use third-part services and products. These will not work with guest account. With SAKI Smart account, you can also allow your family and friends to control your smart air fryer.

**Step 2:** After you logged in to your app. Tap the  icon at the top and select your smart air fryer.

**Step 3:** Select the Auto Scan option at the top for a faster connection. Wait few seconds until the available device is found.

**Step 4:** When available device found hit the Next button below.

**Step 5:** Enter your WIFI name and password to complete connection.