

SAKI

Electric Samovar

Quick Start Guide

What's In The Box



Electric Samovar
Body



Porcelian Teapot



Drip Tray


Control Panel

POWER ON/OFF

Press to power on the unit.
Hold to power off the unit

TEMPERATURE DISPLAY

Monitor water temperature



USING THE ELECTRIC SAMOVAR

Before using the electric samovar:

1. Plug the electric samovar into an outlet.
2. Fill the electric samovar up to MAX line, and run a heating cycle by pressing **POWER ON/OFF** button.
3. Once the boil cycle is complete, discard the water and repeat this process one more time.

2. Press **POWER ON/OFF** button once to start heating cycle. To indicate that the heating cycle has started, the red light ring will illuminate, and the display will show current temperature as it rises.

NOTE: ONLY fill the electric samovar body with water. **DO NOT** heat or boil other liquids.

Powering off:
To manually power off, press and hold the **POWER ON/OFF** button for 3 seconds.

1. Plug in the electric samovar. Fill the electric samovar with the desired amount of water. Put the porcelain teapot on top of electric samovar body.

NOTE: DO NOT start the heating cycle when the electric samovar is empty. If the electric samovar detects there is not enough water in it, the electric samovar shuts off, and the temperature display will read "**NO WATER.**" Plug out from the outlet and let the electric samovar cool for 10 minutes before refilling.

CLEANING, CARE & STORAGE

CLEANING

Unplug your electric samovar and allow it to cool before cleaning. Wipe the electric samovar with a soft damp cloth. Be sure that electric socket is kept dry. Dry all parts after every use.

WARNING: NEVER immerse the electric samovar in water. Instead of washing just wipe the exterior of the samovar body during the keep warm period.

STORAGE

Unplug power cord from outlet and allow electric samovar to cool completely before storing. Follow cleaning instructions and store in an upright position. Do not store anything on top of your samovar. The samovar may be stored on base when not in use.

DESCALING

The electric samovar will not work properly if it is not descaled regularly. Regular descaling can increase the life of the electric samovar, allowing it to boil water faster and with less energy.

Scale is a naturally occurring buildup of mineral deposits caused by impurities in water, especially hard water. For best performance, descale the electric samovar every **4-8 weeks** or whenever scale buildup is present inside.

Descaling can be completed with a descaling solutions specifically designed for kettles. Follow the directions on the descaling solution package,

OR

- 1) Fill the samovat with equal parts water and white vinegar.
- 2) Let sit for **30 minutes**.
- 3) Discard solution and rinse electric samovar thoroughly with clean water.
- 4) Repeat this process until all deposits are removed.

SARI

**For questions or to register your product, contact us at
1-844-331-7333 or visit us online at saki.us**