

## Included Contents:

1 Pair of Hottips!® True Wireless Earbuds

1 Recharaeable Charaina Case

1 Micro-USB to USB-A Charging Cable - 18 in.



## **Operating Functions:**

Pairing Device (1st Way): Remove both TWS earbuds from the charging case and they will automatically start searching for a connection from a Bluetooth® enabled device. Connect to "HOTTIPS TWS" in your device's Bluetooth® settings and a voice prompt will announce "connected."

Pairing Device (2nd Way): Press and hold the Touch Sensitive Function Control Area on both earbuds until they start blinking Blue & Red. They will automatically pair with each other, once successfully linked, connect to "HOTIPS TWS" in your device's Bluetooth® settings and hear a voice prompt "connected."

Playing Audio: Use your connected Bluetooth® device to select and start playing music and audio. Tap the Function Control once to Play or Pause track.

**Volume Control**: Tap the Left Earbud **Function Control** 2 times to turn down the volume and tap 3 times to turn up the volume.

Next Track: Press and hold the Right Earbud Function
Control for 3 seconds to skip to the next track.

Previous Track: Press and hold the Left Earbud Function Control for 3 seconds to return to the previous track.

**Siri Operation:** Tap either earbud's **Function Control** 3 times to turn on Siri. Tap once more to turn Siri off.

Calling: Answer and End incoming calls by tapping either earbud's Function Control once. To reject incoming calls, Press and Hold either earbud's Function Control for 3 seconds.

Turning Off (1st Way): Press and Hold either earbud's Function Control button until a voice prompt announces in "turning off." This will automatically turn off both TWS Earbuds and disconnect from your device.

Turning Off (2nd Way): Insert both TWS Earbuds back into the charging case and close the lid. This will automatically turn off both TWS Earbuds and disconnect from your device.

## Charging:

TWS Earbuds: Place both TWS Earbuds in their respective ports in the Charging Case. If the charging case is charged, the LEDs on the front of the case will light up and automatically start charging earbuds. When the charging is finished, the TWS Earbuds will show Blue LEDs and the charging case will show Green. All lights will then turn off.

Charging Case: Insert Micro-USB connector into the bottom port of Charging Case and insert USB-A end connector into a power source, such as a USB-A port wall or car charger. Each of the 4 LED's will indicate 25%, 50%, 75%, and 100% charged.

## Attention:

- **WARNING:** To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Keep your ears safe! To avoid hearing damage, gradually turn up the volume until you reach a comfortable listening level.
- To lengthen life of battery, fully charge at least once a month.
- Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste, and they should never be incinerated, as they might explode. Contact your local government for disposal or recyclina practices in your area.
- Do not modify, repair or dismantle Hottips!® TWS Earbuds. Doing so may result in fire, electric shock, or complete breakdown of Hottips!® TWS Earbuds. Any of these actions will void the warranty.
- Do not use Hottips!® TWS Earbuds in hazardous locations or while driving.







www.HottipsUSA.com