



www.kalenainstruments.com

Aloha,

Thank you for purchasing a Kalena Ukulele . After enjoying this great product we would appreciate your taking the time to share this experience with other friends and family who could benefit from this exciting product!

This Kalena uke includes an electronic tuner. Photos are on page 3 to show you the battery placement and attachment location to the ukulele. To install or replace the battery remove the battery cover from the back of the tuner and slide the battery firmly in place. The tuner will then light up. When ready to use the tuner, simply press the clamp to open it and release to attach it firmly to the headstock of your Kalena Ukulele. Hold the power button down on the front bottom of the tuner to turn it on and off.

Cleaning and Care

Before and after each use wipe the ukulele down with a soft cloth. It's best to use a little wood polish to protect the wood from scratches and maintain the natural beauty of the instrument. Keep away from harsh or wet environments. Longterm exposure to humidity or heat will cause wood to warp and bindings to loosen. Try not to drop or set down the ukulele on rough or hard surfaces that could damage the instrument. when not using the ukulele it's best to keep it in the provided gig bag.

*Kalena brings Aloha
to your life!*



Place the tuner on the headstock.
The display turns color when the
string is in tune. Remember to
stretch each string!



For ukuleles with built in EQ/tuners simply
press the power button to begin tuning. The
EQ display will automatically track your pitch.



Remember that tuning will take some time as new strings always need to be stretched before keeping in tune. Usually after a day or two the tuning is much easier to maintain. Standard tuning is G-C-E-A, “G” being the top string and “A” being the string closest to your leg.



Before tuning, gently pull on each string repeatedly for about 30 seconds. This will stretch the strings and help to hold the tuning.





Hold the pick firmly in your right hand between your index finger and thumb. Relax your other fingers. Strum up and down bending your wrist.







Note: Left handers can restring the ukulele in the opposite direction. Make sure the order is still correct.

Tuning

| | |
|---|--|
|  <p>G</p> <p>This is the 4th string. It's tone is higher than the 3rd string</p> |  <p>C</p> <p>An old way of tuning by ear is to sing "my dog has fleas"</p> |
| <p>1 T</p> <p>2 A</p> <p>3 B</p> <p>4 0</p> | <p>0 - (3rd String) -</p> |

| | |
|---|--|
|  <p>E</p> <p>Make sure the color changes on the electric tuner before tuning the next string</p> |  <p>A</p> <p>it's best to center the tuner at the end of the headstock</p> |
| <p>3</p> <p>T</p> <p>A 0 - (2nd String) -</p> <p>B</p> | <p>0 - (1st String) -</p> |

chord chart



4/4

C Maj **F Maj** **G Maj**

A 3↑
E 0
C 0
G 0

0↑
1
0
2

2↑
3
2
0

4

C 7 **F 7** **G 7**

T 1↑
A 0
B 0

0↑
1
3
2

2
1
2
0

Do Re Mi

Play a C Maj chord over Do Re Mi

The first system of musical notation for 'Do Re Mi' is in 2/4 time. It consists of a treble clef staff and a three-line TAB staff. The treble staff contains a melody of eighth notes: Do (F4), Re (F#4), Mi (G4), Fa (A4), So (B4), La (B4), Ti (C5), and Do (C5). The TAB staff shows the fret numbers for each note: 0, 2, 0, 1, 3, 0, 2, 3. The notes are grouped into pairs: (Do, Re), (Mi, Fa), (So, La), and (Ti, Do).

Do Re Mi Fa So La Ti Do








TAB 0 2 0 1 3 0 2 3

The second system of musical notation for 'Do Re Mi' continues the melody. It consists of a treble clef staff and a three-line TAB staff. The treble staff contains a melody of eighth notes: Do (F4), Ti (E4), La (D4), So (C4), Fa (B3), Mi (A3), Re (G3), and Do (F3). The TAB staff shows the fret numbers for each note: 3, 2, 0, 3, 1, 0, 2, 0. The notes are grouped into pairs: (Do, Ti), (La, So), (Fa, Mi), and (Re, Do).

Do Ti La So Fa Mi Re Do




TAB 3 2 0 3 1 0 2 0

Happy Birthday





Simple Blues in C



Hold the pick between your thumb and index finger. Strum up and down

C Maj **C Maj**

T A B

Play this with a syncopated shuffle feel

F Maj F 7 **F Maj F 7**


3
T A B



We know you'll love your Kalena ukulele. For any reason, if you are not completely satisfied, please email us so that we may address your concerns before you leave a product review or return the product. We would love to hear from you and are committed to your total satisfaction.

Mahalo,

KALENA INSTRUMENTS



info@kalenainstruments.com

Legal disclaimer:

As with all stringed instruments, playing with too much force may cause pain or injury. Be careful not to place fingers into the sound hole. Applying force to the sound hole may damage the instrument or cause hand injury. Also, playing with too much force may cause the strings to break. If you are not sure how to tune your ukulele after reading this book you can download videos from the internet or ask a professional at a local music store.

You Are My ^CSunshine

My only sunshine.

You make me ^Fhappy

When skies are ^Cgrey.

You'll never ^Fknow, dear,

How much ^CI love you.

Please don't take my ^Gsunshine ^Caway

