
melodysusie



Fondly Pufferfish Sucking Vibrator

User Manual

Vibration Mode



Move this product on your body, including ear back, neck, chelidon, back and waist,inner thigh,pudendum and other sensitive parts,and enjoy it slowly.


Suck Mode

Apply lubricating liquid at the clitoris, fit the mouth of this product with the clitoris. It's better to experience from the lowest gear and enjoys the increasing pleasure of gradual fit.




Fridendly tips

When the mouth fails to fit the skin well,air will go in and out, and there will be a bubble sound, which is a normal phenomenon,but the pleasure will be discounted.




More Exploration

This product can be used on other sensitive parts and allow you to enjoy the highly realistic tender tease.



Mash it with clean water after use,and then put it in the storage box with the base or in a storage bag.



Keep pressing the button **()** for 3 seconds to start the Suck Mode, and click the button to switch among three gears(Slight,Intermediate and Intenseive)

Keep pressing the button ③ for 3 seconds to start the Vibration Mode, and click the button to switch among three gears(Slight, Intermediate and Intensive) and 1 frequency conversion

Keep pressing the same button: on/off

Keep pressing different buttons: Switch between Vibration/Suck Modes

Low battery indicator. When the remaining power can only maintain the operation for 40 minutes,the red light will flash for about 2-3times, accounting for 20% of full power

Status of power shortage: When this product shuts down ,the red light will flash for 6 seconds

Keep pressing the button for two times: Starting the travel lock to avoid awkward situations when this product is started by accidentally hitting the button. Keep pressing the button for two times to unlock for normal use.

Product Specification

Material:	Silicone+ABS	Model:	MS-301
Weight:	Standard weight 110g, including charging cable 123g	Number of Motor:	2
Size:	Product size 94*56*56mm	Battery:	3.7V 420mAh
Charge:	Charge this product through Type-C for 2.5 hours,During char light base will flash,it will go out when full charged.		
Service time:	This product can run for over 2.5hours at the max gear in Suck Mode; This product can run for over 90 minutes at the max gear in Vibration Mode.		
Waterproof level:	IPX6,it can be washed in water.It's better not to use it during soaking.		

Packaging list










Note:This product has no charger.Please charge the product with a daily-used smartphone

①Fondly Pufferfish ②Portable Bag

(3)Instructions

4 Charging



Wash this product thoroughly with clean water before and after use. This product is applicable only to adults who are 18 years old or above. In order to avoid any spread of disease, please do not share the product with others.

When you feel not well, please do not use the product.

Pregnant woman or any person with cardiac pacemaker, diabetes, phlebitis or thrombosis shall consult a medicine specialist for the risk of blood clot before using any private massage products.

Srapping and recycle

Scrapping and Recycle of Electronic Product(applicable to EU and other European countries adopting a separate waste collection system) A symbol of trash can with a "X" means this product shall after scrapping be deemed as a scraped electronic/electrical device and sent to an electronic/electrical device collection station rather than being disposed as general rubbish.









Disclaimer. This product is used at used at users' own risk. Melodysusie and its retailers shall not assume any legal liability arising from the use of this product. Melodysusie reserves the right to modify this instruction without a notice to any person.