



Amazon Alexa Setup

v15

Model NXG-100


NEXX GARAGE ALEXA SKILL SETUP

Nexx Garage integrated with Alexa Skill allows you to control the opening or closing of garage door by voice command.


Following steps describes Nexx Garage Alexa Skill setup.




- 1) Open the Amazon Alexa app on your phone.
- 2) Press menu button in the upper left corner of screen.




3) Select “Skills” from the menu.




4) Search for “Nexx Garage”.



- 5) Select “Nexx Garage” skill and press “Enable” button.



- 6) Press “Link Account” button to go to the login page. Linking account will connect your Amazon account to your Nexx Garage account.




7) At login page:

- Enter Nexx Garage account email and password
- Enter a 4 to 10 digit pin code. This pin code is required by Amazon for security reasons when opening or closing the garage door. Pin code is not required when checking door status. You can disable the pin code from Nexx Garage app under “Settings”.



- 8) Once you have successfully logged in, the message would be received as shown in image below:



NEXX GARAGE ALEXA SKILL SETUP COMPLETED

- Possible Actions
 - “Alexa, tell Nexx Garage to check garage door”
 - “Alexa, tell Nexx Garage to check door”
 - “Alexa, tell Nexx Garage to check garage”
 - “Alexa, tell Nexx Garage to open garage door”
 - “Alexa, tell Nexx Garage to open door”
 - “Alexa, tell Nexx Garage to open garage”
 - “My pin code is 1 2 3 4” (use your pin code)
 - “Alexa, tell Nexx Garage to close garage door”
 - “Alexa, tell Nexx Garage to close door”
 - “Alexa, tell Nexx Garage to close garage”
 - “My pin code is 1 2 3 4” (use your pin code)

Note:

You can disable/enable pin code from Nexx Garage app under “Settings”.