



Air-Checks Indicator

REF PL 397

Directions For Use

INDICATIONS FOR USE

The Air-Checks indicator is used as an indicator for steam/air retort processing. The purple indicator ink turns green when exposed to steam/air pressure processing.

COLOR CHANGE

Purple to Green

COMPLETE COLOR CHANGE TIME

2 min. @ 250°F/121°C Saturated Steam

INSTRUCTIONS FOR USE

1. Attach one Air-Checks processing indicator to each basket before retorting.
2. After retort processing, inspect each indicator, Indicator ink bar changes color from purple to green during retort processing. If the indicator bar is not completely green, notify supervisor.

STORAGE

Air-Checks Indicators should be stored at normal room temperatures: 50°-100°F (10°-38°C). Protect from moisture and excess humidity.

EXPIRY DATE

The expiry date is printed on product packaging.

LOT NUMBER

A unique identification code, **LOT**, is printed on each Air-Checks Indicator and on the bag and case labels.

Manufactured For:
Temperature Indicators Ltd
The Old Bakery, Ashley Gardens
Rusthall, Tunbridge Wells
Kent, TN4 8TU, United Kingdom
Tel: +44 (0) 1892 514444 Fax: +44 (0) 1892 514411