

New body manual dim radar install-250712 + 250715

Connection point is on the passenger side of the dashboard. Remove side access panel by simply pulling side trim off.

Locate and remove the 10 amp fuse from location # 23. Install this removed fuse into our fuse assembly so that it now has 2 fuses in it. Then install the fuse assembly back into #23.

Connect the ground wire to a known good ground. See pictures

Route the harness up the windshield pillar and tuck the harness behind it using a plastic pry tool. Do the same along the top edge of the headliner and route the cord to the area of your choice.











