


Advanced  PureAir®

APA-5000z AIR PURIFIER

Owner's Manual



Produced and distributed exclusively by:

 **REAL SPIRIT**
an innovative products group

v 1.03

www.AdvancedPureAir.com

Contents

Features	02
Product Information	03
How to Use	05
Maintenance	07
Troubleshooting	08
Warranty	09

NOTE: Plastic wrap on filter must be removed before use.

***See page 6 for more information.**

Dear Customer,

Thank you for choosing the APA-5000z Air Purifier.

Our newly introduced APA-5000z Air Purifier will help you have a cleaner, germ-free healthier home!

Your new Air Purifier is meticulously designed with high quality state-of-the-art materials and components.

Please read this owner's manual carefully to familiarize yourself with the special features and functions of your air purifier.

Keep this owners manual in a safe place for future reference.

Should you have any further questions or need assistance, call our Support line at 1-888-601-5886.

Thank you again for choosing Advanced Pure Air®.

FEATURES

Key Features

- Elegant and cozy, creating a favorable environment for your bedroom or office.
- Effective air cleaner: excellent air flow rate.
- ON/OFF - Timed Activated Oxygen (Ozone) Feature.
- HEPA filter will allow your room to be free from dust and odor.
- Energy-efficient and safe: brushless motor, 110/220V low-voltage DC, Max power consumption <20 W.


Caution

- Use only Original power adapter, in case the adapter or wire is damaged, please contact our Customer Center.
- DO NOT touch the plug with wet hands, it may cause electric shock.
- Unplug the power cord when you clean the unit.
- Disconnect the power supply before replacing the filter, or if the unit is not to be used for a long time.
- If there is damage to the adapter, power wire or the socket, do not use the unit or plug the unit into socket.
- Before connecting the unit with the electric power, please check if the power provided in accordance with the rated power of the product.
- DO NOT put any object inside the unit either in inlet or outlet.
- DO NOT block the inlet or the outlet of the unit, for this will prevent the air flow and reduce the effectiveness of air purification.
- The unit must be sent to the repair center authorized by our company for service.
- DO NOT repair the product yourself, doing so will invalidate the warranty.
- DO NOT run the unit without filter, the entry of dust may cause problems in the equipment and its components.
- DO NOT use the unit in a bathroom, it may cause electric shock.
- To protect against electrical hazards. DO NOT immerse the unit in water or other liquids.
- Keep the unit away from water, heater, and fire.

NOTE: If your breathing or lungs become irritated while using "O" Mode, turn off when operating while occupying the room


PRODUCT INTRODUCTION

General Instruction (Fig. 1)



PRODUCT INTRODUCTION

Components




Getting Started

- Turn the Air Purifier upside down after unpacking it.
- Rotate the base cover to take out the filter and follow the guide arrow.
- **IMPORTANT: Remove outer plastic wrap from new filter before use. Replace the filter after removing the packing. Take care to rotate the base cover in reverse direction.**
- Keep the unit on a dry, stable and firm surface in straight, upright position.
- Insert the power adapter of the air purifier to the main power supply.
- After switching the on button, "BEEP" sound, all indicator lights will flash once, indicating that the product is powered on.

HOW TO USE

Control Panel



A. Power Button	B. "O" Mode (Ozone) Button	C. Air Flow Speed Select Button
D. Air Flow Speed Indicator	E. Auto Mode Button	F. Sleep Mode Button
G. Timer Switch Button	H. Filter Reset Button	I. Timer Display / Filter Life

How to use

Start:

Plug the 5000z into a power outlet (110/120V AC)

Turn on with switch (on back), then press the Power Button.

The Air Quality indicator will light up, and run on speed level 1.

AUTO run mode:




Press the [AUTO] button and it will go into the auto run mode. In the [Auto] mode, the auto indicator will glow and the unit automatically adjusts the air flow depending on the indoor air quality. The Air Quality indicator will change color to the corresponding level of air quality.

Sleep mode:

Press the [SLEEP] button after the start or in the other mode, it will go into the sleep mode. In this mode the sleep indicator will light and the unit will run at speed level 1.

HOW TO USE

AIR QUALITY INDICATOR

	Blue	Excellent
	Green	Good
	Purple	Average
	Red	Poor

Manual mode:

Press the [Air Flow Speed Select] button after the start or in any other mode, it will operate in manual mode. In this mode, the corresponding speed indicator will light and the unit will run at the selected speed. You can change the speed by pressing the [Air Flow Speed Select] button.

"O" Mode (Ozone) Button

Press the ["O" MODE] button and it will go into the "O" mode. In this mode "O" Mode (Ozone) will operate for 30-60 minutes, after which "O" Mode (Ozone) can be restarted by pressing "O" Mode button as needed. DO NOT remain in room if irritation occurs while ozone cleaning feature is activated. The APA-5000z produces Ozone within the designated room size below the USA standard maximum, as stated: "On October 1, 2015, the U.S. EPA lowered the national eight-hour standard from 0.075 ppm to 0.070 ppm." Our ozone "O" feature is set at no higher than 0.050 ppm.

Timer function:

Press the [TIMER] button and it will go into the timer mode. In this mode you can set the specific time between 0.5-24hrs to automatically switch off the unit. The set time will be indicated on the display.

Stop function:

If you want to switch off the unit completely press the [Power] button, the unit will switch off and all lights will go off.

Filter reset button function:

Press this button when starting up, the button lamp light and the display will show the residual life of filter "%," 3 seconds later, it will turn back on. When the filters need to be changed, the button light will blink. After replacing filters, press this button for 5 seconds to reset. You will also need to do this when the 5000z does not operate. It allows you to "re-boot" the filter reset, and normal function will resume.

MAINTENANCE

Maintenance

Before attempting to perform any maintenance on the unit, disconnect the power adapter.

Filter

Suggested time of changing filter: **about every 3 months**

It depends on different locations and usage level. For example, changing time of filter may be shorter in contaminated zones or smoking areas, etc. Please change the filter if the purification results are not good.


Cleanup routine: biweekly - use soft brush or dry cotton cloth to clean the filter surface only. Do not use water to wash the filter.

Do not force press or pull, because the filter can be broken or deformed easily. Please change to new filter before using if it is damaged. Whenever you change the filter, hold down the "Filter Reset" button until it beeps.

Cylinder inner surface cleaning

Notice

1. Keep surface of the sensor clean, or sensitivity is affected and will fail to work.
2. Recommended cleaning cycle is less than 1 month for daily use.
3. Clean the sensor with a cotton swab as shown in the picture below. Do not use detergent or any liquid in the cleaning process.



External surface

Please use dry soft fabric to wipe the surface, inlets and outlets. Do not use a chemical cleaning agent.

During long periods of no use

Unplug the unit from socket.

Clean the surface and filter.

Store in a dry and cool place and cover with plastic bag.

TROUBLESHOOTING

Problem	Solution
Unit will not operate	<ol style="list-style-type: none">1. Check if air purifier is properly plugged in and powered on2. Make sure unit is turned ON3. Hold down Filter Reset Button.
Smell	<ol style="list-style-type: none">1. Filter is too dirty because it's not replaced for a long time - replace the filter2. Using the air purifier in moist conditions or water entered the filter - Replace filter3. Using unclean filter for a long time or completely blocked filter - Clean the filter, if problem is not resolved, replace the filter4. Burning smell - Stop the air purifier immediately and turn off the power; contact our customer service department: 1-888-601-5886
Excessive Noise	<ol style="list-style-type: none">1. Make sure parts are firmly positioned in place2. Open the base cover and make sure that any plastic packaging was removed from the filter
No air flow	<ol style="list-style-type: none">1. Air purifier being operated in sleep mode - change the mode2. The air purifier is malfunctioning - check power supply if problem still exists, contact your Customer Service3. Open the base cover and make sure that any plastic packaging was removed from the filter
Ineffectiveness	<ol style="list-style-type: none">1. The filter is blocked and no longer is effective - replace the filter2. Being used in wrong environment such as an oversized room

PRODUCT WARRANTY

- Advanced Pure Air® warrants their air purifiers to the original consumer purchaser to be free from defects in materials and workmanship under normal operation and use for a period of three (3) years from the date of original purchase. Under the terms of the warranty, Advanced Pure Air® will repair or replace any defective part(s) free of charge.
- This warranty is valid only to the original owner with proof of purchase.
- Product abuse, misuse, modification, alteration, or opening the unit housing, other than as required for filter replacement or routine maintenance and cleaning (as described in the owner's manual), will void the warranty. Spraying fabric cleaners or deodorizers into the product will cause damage and void the warranty. Use in a commercial application or marine environment is not authorized, this product is not intended to be used where salt spray is present and will void the warranty.
- Should the product fail during the warranty period, you must return the air purifier in original carton or same size acceptable shipping carton prepaid shipping via UPS, FedEx, or USPS to the address below. Accompanied by your name, address, telephone number, proof of purchase date and a description of the defect.
- Upon inspection, if under warranty Real Spirit USA will repair or replace with a new or refurbished unit, or an upgrade to similar or higher grade product. Shipping paid back to original purchaser Real Spirit USA (within the contiguous United States).
- The warranty does not include unusual wear, damage resulting from accident or unreasonable use and also does not include replacement filters or other disposable/consumable parts.

QUESTIONS?

CALL: 1-888-601-5886

Model	APA-5000z
Adapter Power Supply	Input-110/220V AC/Output-DC24V
Unit Power Supply	12V DC, 2A
CADR	100 m ³ /hr
Noise Level	Max: 56 dBA Min: <25dBA
Dimensions	8.5"x8.5"x13" (220*220*331 mm)

Produced and distributed exclusively by:



Advanced Pure Air® is a division of Real Spirit USA, Inc.
320 South Rock Blvd Suite 210 • Reno NV 89502 • Ph 888.601.5886
www.AdvancedPureAir.com • info@advancedpureair.com