

Ethnicraft

CARE INSTRUCTIONS

BOWLS & BOARDS

ABOUT US

TIMELESS DESIGN

All our designs are intentionally timeless. They withstand trends and associate well with different styles, and they can be passed on from one home to the next, carrying over the stories of one lifetime into another. Our collections go back to the essence of what we believe is good design: pieces full of character, made from quality materials that age beautifully. We love that solid wood evolves with the years as it carries the marks of the life that happens to it.

We create collections for every room or space: from the furniture that defines the purpose of an area, to the objects that layer it with meaning. Nothing excites us more than seeing how people love and use our products in the story of their life.

UNIQUENESS OF THE PRODUCT

Our products are created using classic and traditional carving techniques. Due to their handcrafted nature, each item will vary. We consider this a sign of uniqueness and quality.

Ethnicraft

USER INSTRUCTIONS

Our bowls and boards are finished with a food safe varnish. This means they will not contaminate any solid or dry foods they come in contact with.

We would also like to highlight the following remarks:

- This food safe varnish is intended for solid, dry, foods only, such as biscuits, lightly-oiled salads and bread. It is not intended for liquid foods such as soup, pasta, fruit salad or cereal with milk.
- Don't expose your bowl or board to hot foods over 60 °C/ 140 °F
- Please wash the item before use as per the recommended care instructions.
- Don't use any metal utensils or cutlery that could potentially scratch the surface of the bowl and board.
- Don't put your bowl or board in the microwave, as the heat may damage it.
- Don't leave your bowl or board in the fridge, as the moisture can cause cracks and warping.

CARE INSTRUCTIONS

We recommend the following:

- Hand-wash only. Do not place your bowl or board in the dishwasher.
- For regular cleaning, use a damp cloth. In case of a stain, use regular dish soap, then dry the item at room temperature immediately.
- Do not soak or submerge your item in water.
- Items that contain natural cracks in the wood and design should not be cleaned with water as moisture can seep into the inner layers and cause mould growth. Instead, we recommend cleaning with a damp cloth only.

TIPS & TRICKS

- This product is intended for indoor use only.
- Recommended humidity in the room: between 40% and 60%.
- Ideal room temperature: between 14 °C/57 °F and 21 °C/70 °F.
- To prevent colour differences, do not place your object in direct sunlight.
- Avoid exposure to extreme conditions: do not place your object near heating sources or air-conditioners.

*We create the foundations of your home,
to inspire the stories of your life.*

Ethnicraft

www.ethnicraft.com

Join us @ethnicraft

