

Synth Controller manual addendum for edition '8000' for Korg DW-/EX-8000

If your DW-/EX-8000 does not want to respond to the controller:

- a) are the midichannels of synth and controller identical?
- b) is the parameter #85 of the synth set to value 2 ('All Data')?