

Synth Controller manual addendum for editions '8P' for Roland JX-8P

If your JX-8P does not want to respond to the controller:

- a) are the midichannels of synth and controller identical?
- b) is the midi menu-parameter #26 of the JX-8P set to 'EXCLUSIVE ON'?

Firmware-Update 3.1 – 01.2017

Since firmware V 3.1 Keyfollow for Env1 & Env 2 can be changed:

The two parameters 'Env1 Keyfollow' and 'Env2 Keyfollow' are 'Shift' parameters. To change them, please hold the blue button. While blue is released the normal Envelope Release parameters are active.

Keyfollow got 4 steps: Off (leftmost), 1, 2 and 3.