

Synth Controller manual addendum for edition '1OH1' V 3.3

Starting with Firmware V3.3 the LFO RATE can also be adjusted in FINE steps, before the LFO RATE changed COARSE. If one of the upper buttons is active, everything is like before: LFO RATE adjusts the rate in coarse steps. If the 3rd button is lighted LFO RATE is adjusted in fine steps.