



800-516-9287 | INNOPLAST.com

Innoplast's full product line includes:

at 100% Scale to assist in measuring (Diagram is at 100% Scale).





BollardGard[™] Easy Installation

Our Patented Gripper Tabs™ installation method is the fastest and most secure in the industry.

- 1. Adhere three or four self-adhesive Gripper Tabs evenly spaced around the top and base of the steel bollard with "gripper fingers" pointing down. (Use four Gripper Tabs at the top and base when filling larger spaces.)
- 2. Place the BollardGard cover over the steel bollard. Gripper Tabs should provide a tight fit between the bollard and cover, which cannot be easily removed.

Standard Sizes

	52" H	60" H	64" H	72" H
Diameter				
4"	•		•	
7"	•	•		•
8"				•
11"		•		

All covers can be custom cut to length at no additional charge.

Fits 4" nominal steel pipe, all schedules (4.500" pipe 0.D.)

4" Diameter (4.700" ID) x 52" Long

4" Diameter (4.700" ID) x 64" Long

Fits 6" nominal steel pipe, all schedules (6.625" pipe 0.D.)

7" Diameter (7.125" ID) x 52" Long

7" Diameter (7.125" ID) x 60" Long

7" Diameter (7.125" ID) x 72" Long

Fits 8" nominal steel pipe, all schedules (8.625" pipe 0.D)


8" Diameter (8.875" ID) x 72" Long

Fits 10" nominal steel pipe, all schedules (10.75" pipe 0.D)

11" Diameter (11.125" ID) x 60" Long

Our vision at INNOPLAST is to provide the best quality facility protection products in the industry at a price you can ALWAYS afford.

We strive to protect your facility in a cost-efficient way by adding VALUE to your assets and reducing maintenance costs.







YouTube www.youtube.com/user/innoplastBoliards

