



MXTA-SERIES

PRESSURE/TORQUE CONVERSION CHART

10MXTA

PRESSURE IN				
PSI	FT.LBS	KGM	NM	BAR
1500	1755	243	2379	104
1600	1864	258	2527	110
1800	2082	288	2822	124
2000	2300	318	3118	138
2200	2526	349	3424	152
2400	2752	381	3731	165
2600	2978	412	4037	179
2800	3204	443	4343	193
3000	3430	474	4650	207
3200	3656	506	4956	220
3400	3882	537	5262	234
3600	4108	568	5569	248
3800	4334	599	5875	262
4000	4560	631	6182	276
4200	4792	663	6496	290
4400	5024	695	6811	303
4600	5256	727	7125	317
4800	5488	759	7440	331
5000	5720	791	7754	345
5200	5948	823	8063	358
5400	6176	854	8372	372
5600	6404	886	8681	386
5800	6632	917	8990	400
6000	6860	949	9299	414
6200	7094	981	9617	427
6400	7328	1013	9934	441
6600	7562	1046	10251	455
6800	7796	1078	10568	468
7000	8030	1111	10885	482
7200	8264	1143	11203	496
7400	8498	1175	11520	510
7600	8732	1208	11837	524
7800	8966	1240	12154	538
8000	9200	1272	12472	552
8200	9432	1304	12786	565
8400	9664	1337	13101	579
8600	9896	1369	13415	593
8800	10128	1401	13730	607
9000	10360	1433	14044	620
9200	10592	1465	14359	634
9400	10824	1497	14673	648
9600	11056	1529	14988	662
9800	11288	1561	15302	676
10000	11520	1593	15617	690

REVISED: 01/03/2012

Hytools NZ
279 Mt. Smart Road
Onehunga, Auckland

Phone: (09) 636 2264

Fax: (09) 636 2265