



## LXT-SERIES

### PRESSURE/TORQUE CONVERSION CHART

18LXT

PRESSURE IN				
PSI	FT.LBS	KGM	NM	BAR
1500	2676	370	3628	104
1600	2854	395	3869	110
1800	3209	444	4351	124
2000	3565	493	4833	138
2200	3922	542	5317	152
2400	4279	592	5801	165
2600	4636	641	6285	179
2800	4993	691	6769	193
3000	5350	740	7252	207
3200	5708	789	7738	220
3400	6066	839	8223	234
3600	6424	888	8708	248
3800	6782	938	9194	262
4000	7140	987	9679	276
4200	7496	1037	10162	290
4400	7852	1086	10644	303
4600	8208	1135	11127	317
4800	8564	1184	11609	331
5000	8920	1234	12092	345
5200	9277	1283	12576	358
5400	9634	1332	13060	372
5600	9991	1382	13544	386
5800	10348	1431	14028	400
6000	10705	1481	14512	414
6200	11062	1530	14996	427
6400	11419	1579	15480	441
6600	11776	1629	15964	455
6800	12133	1678	16447	468
7000	12490	1727	16931	482
7200	12848	1777	17417	496
7400	13206	1826	17902	510
7600	13564	1876	18387	524
7800	13922	1925	18873	538
8000	14280	1975	19358	552
8200	14637	2024	19842	565
8400	14994	2074	20326	579
8600	15351	2123	20810	593
8800	15708	2172	21294	607
9000	16065	2222	21778	620
9200	16421	2271	22260	634
9400	16777	2320	22743	648
9600	17133	2369	23225	662
9800	17489	2419	23708	676
10000	17845	2468	24191	690

REVISED: 08/1994

Hytools NZ  
279 Mt. Smart Road  
Onehunga, Auckland

Phone: (09) 636 2264

Fax: (09) 636 2265