



XTA-SERIES

PRESSURE/TORQUE CONVERSION CHART

25XTA

PRESSURE IN PSI	FT.LBS	NM
1000	2523	3419
1250	3153	4272
1500	3784	5127
1750	4415	5982
2000	5046	6837
2250	5676	7691
2500	6307	8546
2750	6938	9400
3000	7568	10255
3250	8199	11109
3500	8829	11964
3750	9460	12818
4000	10091	13673
4250	10722	14528
4500	11352	15382
4750	11983	16237
5000	12614	17091
5250	13244	17946
5500	13875	18801
5750	14506	19655
6000	15136	20510
6250	15767	21364
6500	16398	22219
6750	17029	23074
7000	17659	23928
7250	18290	24783
7500	18921	25637
7750	19551	26492
8000	20182	27347
8250	20813	28201
8500	21443	29056
8750	22074	29910
9000	22705	30765
9250	23336	31620
9500	23966	32474
9750	24597	33329
10000	25228	34183

REVISED: 21/09/12

Hytools NZ
279 Mt. Smart Road
Onehunga
Auckland

Phone: (09) 636 2264

Fax: (09) 636 2265