



XTA-SERIES

PRESSURE/TORQUE CONVERSION CHART

3XTA

PRESSURE IN PSI	FT.LBS	NM
1500	492	667
1750	524	710
2000	656	889
2250	738	1000
2500	820	1111
2750	901	1221
3000	983	1332
3250	1065	1443
3500	1147	1554
3750	1229	1665
4000	1311	1776
4250	1393	1888
4500	1475	1999
4750	1557	2110
5000	1639	2221
5250	1721	2332
5500	1803	2443
5750	1885	2554
6000	1967	2665
6250	2049	2776
6500	2131	2888
6750	2213	2999
7000	2295	3110
7250	2377	3221
7500	2459	3332
7750	2540	3442
8000	2622	3553
8250	2704	3664
8500	2786	3775
8750	2868	3886
9000	2950	3997
9250	3032	4108
9500	3114	4219
9750	3196	4331
10000	3278	4442

REVISED: 21/09/2012

Hytools NZ
279 Mt. Smart Road
Onehunga
Auckland
Phone: (09) 636 2264

Fax: (09) 636 2265