



Installation Instructions for IUP015R  
Nissan Patrol Y61  
Underbody Protection Plate

Radiator and Steering




**NISSAN Patrol** (Y61; 3,0D; 4,8) **2005 - 2010** 

IUP015R

1/6





Location/Position Arrow



Movement Arrow




Screw Arrow




IUP015R

**A**


1X

**B**

2X


**C**

2X

**D**


M10x30

2X

**E**


Unique Washer

2X

**F**


M10x20

6X

**G**


Ø 8

4X

**H**

M8x20

4X

**I**



Ø 10



8X





IUP015R

3/6









Installation Instructions for IUP015T  
Nissan Patrol Y61  
Underbody Protection Plate

Transmission




**NISSAN Patrol** (Y61; 3,0D; 4,8) **2005 - 2010** 

IUP015T			1/7
---------	--	--	-----





Location/Position Arrow



Movement Arrow



Screw Arrow



IUP015T

217



<b>A</b>		1X
		1X

<b>B</b>	<p>M10x90</p>	2X
----------	---------------	----

<b>C</b>		2X
----------	--	----

<b>D</b>	<p>M10x20</p>	5X
----------	---------------	----

<b>E</b>	<p>M10</p>	2X
----------	------------	----



<b>F</b>	<p>M8x30</p>	5X
----------	--------------	----


<b>G</b>	<p>∅ 8</p>	9X
----------	------------	----

<b>H</b>	<p>M8x20</p>	4X
----------	--------------	----


<b>I</b>	<p>∅ 10</p>	9X
----------	-------------	----

<b>J</b>		1X
----------	--	----





3




4




IUP015T

5/7



**5**




**6**



IUP015T

6/7



7



IUP015T

717