

WIRING DIAGRAM FOR SINGLE COIL

Single Coil Sized

Orange to selector switch
White with black stripe to ground
Green to ground.

The phase of the Alumitone and Lace Sensors can be changed by having the white with black stripe connect to the selector switch and the orange and green connect to ground. To split refer to the Alumitone Normal/Split Wiring Diagram.

