


WIRING DIAGRAM FOR SINGLE COIL, HUMBUCKER, HUMBUCKER SPLIT AND DUALLY MODE




STANDARD WIRING FOR HUMBUCKER



STANDARD WIRING FOR HUMBUCKER INTO SINGLE COIL



The Lace Sensor Dually can be wired for "Dually" mode: front coil/both coils/rear coil for 3 tones in one. Use SPDT on/off/on mini toggle switch. This also works for all Lace Sensor Humbuckers (excluding Alumitones)



© Lace Music Products

