General Instructions



It is not unusual that upon using the grill for the first time, there may be an odor of burnt paint. This is a normal part of the paint curing process and is rarely to repeat itself in the future



Remember never to touch any metal surfaces of the grill while it is in use, as it can produce severe burns.



It is best to store the grill unit in a dry place, moisture may result in oxidization.





IGNORING THE NOTICE AND WARNINGS OF POTENTIAL HAZARDS
CONTAINED IN THIS OWNER'S MANUAL MAY RESULT IN SERIOUS PERSONAL
INJURY UP TO AN INCLUDING DEATH, OR POTENTIALLY CAUSE FIRE OR
EXPLOSION THAT MAY CAUSE PROPERTY DAMAGE.

All of us at Nuke appreciate your choice of our product and the trust you place on us.

WELCOME TO THE NUKE FAMILY!





The security symbols ($\underline{\Lambda}$) will alert you to important information.




Read all safety information contained in this Owner's Guide before operating the grill.

- Do not use grill for indoor cooking. This grill must only be used outdoors. If used indoors, toxic carbon monoxide fumes can accumulate and cause asphyxiation.
- ⚠ Do not leave grill unattended. Keep children and pets away from grill at all times.
- Do not touch metals part of grill until they have completely cooled to avoid burns, unless you are wearing protective gear (pot holders, gloves, BBQ mittens, etc).
- Never use charcoal that has been pre-treated with lighter fluid. Use only a high grade plain charcoal, charcoal/wood mixture, lump charcoal or cooking wood.
- ⚠ Do not remove the ashes until the charcoal has burned completely and the grill has cooled off.
- Keep the grill at all times on a safe and level surface, away from combustible materials.
- Do not discard hot coals where they could cause injury or pose a fire risk.


11

ASSEMBLY

Grill height control




To build your grill follow the instructions below.




ASSEMBLY FUNCTIONING

Once the grill has been removed from the base, attach the fixed and rotating wheels, as described below.




Placement of fixed wheels.



Placement of rotating wheels

3, to ensure it remains properly attached.




Position the rotating wheels by fastening them with the 5/8 "bolts to the base plate of the grill.

Starting the fire Light the fire in the fire preparation area by using charcoal or a soft firewood. Fire preparation area. As the fire begins to generate embers they will fall through the grill and under the stoker. Once you have a good amount of embers, drag them to the embers area. Ember area.

To guarantee the correct operation of your grill, follow the instructions indicated below.

4

9



DIMENSIONS COMPONENTS

When using your grill, take the following dimensions into account.

