JACK MASON




HALYARD SPORT

Nautical Chronograph 42mm

JM-N122-003

Miyota Caliber No. 0S20 Chronograph Function



Setting The Time

- 1. Pull the crown out to the **2nd position**.
- 2. Turn the crown to set Hour and Minute Hands.
- 3. When the crown is pushed back to the **Normal position**, **Small Second Hand** begins to run.

Setting The Date

- 1. Pull the crown out to **1st position**.
- Turn the crown counter-clockwise to set the date.
 *Set the date between the hours of 2:00 am to 8:00 pm to ensure the date changes the following day.
- 3. After the date has been set, push the crown back to Normal position.

Using The Chronograph Function

This chronograph will measure and display time in 1/1 second units up to a maximum of 59 minutes 59 seconds. The chronograph second hand keeps continuously for 59 minutes 59 seconds after starting.

Measuring time with a Chronograph:

- 1. The chronograph can be started and stopped each time **Button** A is pressed.
- 2. Pressing Button B resets the chronograph and the Chronograph Second Hand and Chronograph Minute Hand return to zero position.

Chronograph Reset

This Procedure should be performed when the **Chronograph Second Hand** does not return to zero position after the chronograph has been reset, and including after the battery has been replaced.

- 1. Pull the crown to the **2nd Position**.
- 2. Press **Button A** to set the chronograph second hand to the zero position. The chronograph hand can be advanced rapidly by continuously pressing **Button A**.
- 3. Once the hands have been zeroed, return the crown to Normal Position.

*Do not push crown to **Normal Position** while the **Chronograph Second Hand** returns to zero position. It stops on the way when crown are returned to **Normal Position** and its position is recognized as zero position.