

THE BEST BRANDS, THE BEST PRODUCTS

Your one stop shop for all sauna and steam needs.

saunas.com (888) 503-8157 info@saunas.com 6700 N Linder #152-180 Meridian, Idaho 83646

2021

Specifications



Dimensions

Product Depth (in.)	4.5
Product Height (in.)	8.5 in
Details	
Bulb Type Included	No Bulbs Included
Exterior Lighting Accessory	Wall Mount Light
Туре	
Exterior Lighting Product	Bulkhead Lights
Туре	
Fixture Color/Finish	Black
Glass/Lens Type	Frosted
Included	Hardware Included
Light Bulb Base Code	Medium
Maximum Bulb Wattage	60 W Appliance
Maximum Wattage (watts)	60

Product Length (in.)	4.5 in
Product Width (in.)	5 in

Number of Bulbs Required	1
Outdoor Lighting Features	Rust Resistant,Water
	Resistant,Waterproof,
	Weather Resistant
Power Type	Hardwired
Product Weight (lb.)	1.69 lb
Recommended Light Bulb	A19
Shape Code	
Size	Small
UL Listing	1-UL Listed

saunas.com (888) 503 8157 info@saunas.com 6700 N Linder #152-180 Meridian, Idaho 83646

Flush-Mount Fixture Wiring Instructions

Ground Screw

Ground Wire

Fixture

NOTE: ALWAYS TURN POWER OFF BEFORE INSTALLING LIGHTING FIXTURES! IMPORTANT: YOU SHOULD USE A QUALIFIED ELECTRICIAN TO INSTALL THIS FIXTURE.

Installation (see fig. A)

1. Disconnect power at main electrical panel before installation. 2. Thread the mounting screws into the same side of the mounting strap as the Green ground screw.

3. Guide fixture wires through hole in center of mounting Supply Ground Wire strap.

4. Follow wiring instructions carefully (listed below).

Box Screw 5. Attach mounting strap to outlet box using bos screws provided with outlet box.

6. Mount fixture by aligning mounting holes in base with mounting screws. Positioning the mounting screw heads through the large openings of the keyhole shape slots. Rotate the fixture to seat the mounting screws, tighten mounting screws securely.


Wiring (see fig. B)

1. Split the conductors of the fixture wire about 4 inches, being careful not to expose any of the wire inside of the insulation.

2. Connect the fixture ground wire to the outlet box ground wire using wirenut (not provided). Connect outlet box ground wire to mounting strap with GREEN hex-head ground screw to tapped hole in mounting strap marked "GDN".

3. Connect the half of the fixture wire that is white, marked, or has a ribbed surface to the outlet box supply wire (WHITE). Connect the other half of the fixture wire that is black, unmarked, or has a smooth surface to the outlet box supply wire (BLACK or RED). Use wirenuts provided.

4. Spread the electrical splices so that the black wire are on one side of the outlet box and the white wire are on the other side.





Fia. A

Outlet Box

Fixture Wires

Fixture Wires


Box Screw

Mounting Screw

Base

Mounting Strap

White, Marked, or Ribbed Fixture Wire




Black, Unmarked, or Smooth Fixture Wire



Black or Red Supply Wire

saunas.com (888) 503 8157 info@saunas.com 6700 N Linder #152-180 Meridian, Idaho 83646

Flush-Mount Fixture Assembly Instructions II



saunas.com (888) 503 8157 info@saunas.com 6700 N Linder #152-180 Meridian, Idaho 83646

S