



LED DOWNLIGHT

Installation Instructions







Warning

1. Installation only to be carried out by a qualified electrician.
2. Make sure all electrical connections are in accordance with the safety codes.
3. Turn off power at fuse or circuit breaker before installation or servicing.
4. Pre-cut the hole before installation (see below chart for the hole diameter).

Model	Dimension(mm)	Cut-Out(mm)
DR-7W	90(Ø)*42(H)	80(Ø)
DR-12W	120(Ø)*42(H)	105(Ø)
DR-18W	145(Ø)*42(H)	130(Ø)
DR-24W	170(Ø)*42(H)	155(Ø)
DR-36W	220(Ø)*42(H)	205(Ø)



Installation

<p>1</p>  <p>Turn off the power.</p>	<p>2</p>  <p>Cut a hole in the ceiling.</p>	<p>3</p>  <p>Connect the driver to mains electricity in accordance with current wiring regulation.</p>
<p>4</p>  <p>Connect the downlight to the driver.</p>	<p>5</p>  <p>Push back the spring clips and insert the downlight into the ceiling.</p>	<p>6</p>  <p>Ensure the downlight is a flush fit to the ceiling.</p>