



# RIMLESS LED PANEL LIGHT


## Installation Instructions

### Warning

1. Installation only to be carried out by a qualified electrician.
2. Make sure all electrical connections are in accordance with the safety codes.
3. Turn off power at fuse or circuit breaker before installation or servicing.
4. Pre-cut the hole before installation (see below chart for the hole diameter).









| Model      | Dimension(mm) | Cut-Out(mm) |
|------------|---------------|-------------|
| ADJ-RD-9W  | 90(∅)*19(H)   | 50-80(∅)    |
| ADJ-RD-18W | 125(∅)*20(H)  | 70-110(∅)   |
| ADJ-RD-24W | 175(∅)*21(H)  | 70-160(∅)   |
| ADJ-RD-36W | 225(∅)*22(H)  | 70-210(∅)   |



Adjustable Cut-Out Size

### Installation

|   |  |  |
|---|--|--|
| <p><b>1</b></p>  <p>Turn off the power.</p>                  | <p><b>2</b></p>  <p>Cut a hole in the ceiling.</p>  | <p><b>3</b></p>  <p>220-240V AC</p> <p>Connect the driver to mains electricity in accordance with current wiring regulation.</p> |
| <p><b>4</b></p>  <p>Connect the downlight to the driver.</p> | <p><b>5</b></p>  <p>Push back the spring clips and insert the panel light into the ceiling.</p> | <p><b>6</b></p>  <p>Ensure the panel light is a flush fit to the ceiling.</p>   |