## PRODUCT SPECIFICATION

Material	ABS	Solar Panel	3.1 x 3.1 inch / 1.5 W
Battery	Li-ion battery 18650 2200mAh	Waterproof Performance	IP65
Size	4.48 x 29.92 inch	Accessories	1*Lighting section 1*Lower section 1*Ground spike 1*User manual

This product has a 1-year limited warranty. For further information please visit our website at www.techkogroup.com

Copyright Reserved Patent Pending: US 16/279. 107; CN201920118689.6

Solar Garden Light - Flame or Still Light

USER MANUAL




Model: SGL-401

- ▲ Please carefully read this manual before using the product.
- ▲ Keep the manual with you for reference as needed.


### PLEASE FULLY CHARGE THE PRODUCT BEFORE USING

- 1. Secure the unit and fully charge in direct sunlight and select desired operating mode (flame or still) before use.
- 2. Charging time may vary depending on the weather, temperature and seasons.
- 3.Do not place the product indoors or any place where there is no direct sunlight, the product will not charge properly.
- 4.Keep the solar panel clean to ensure the product can be properly charged. Frequently clean the solar panel as needed. Avoid scratching on the panel or it may lower charging efficiency.


### INSTALLATION INSTRUCTIONS




 Pull the ground spike out from inside the lower section.



2. Carefully insert the ground spike into the lower section matching the notches together.



3. Carefully insert the lighting section into the lower section matching the notches together.




4. Position the ground spike and press firmly to secure the solar garden light into the ground.

- ▲ Please install the unit in a place where the solar panel can be continually exposed to the sun.
- ▲ Avoid placing the unit where shade from buildings or objects would block the solar panel.
- ▲ The switch is on the top of the solar unit.
- ▲ The product can be charged in all operating modes. The solar panel is equipped with daylight sensor. The product will charge in direct sunlight during the daytime and automatically turn on at dusk

# SWITCH & FUNCTIONS (Please see Figure A for reference)

- 1. Flame Mode: Slide switch to the "Flame" position. The light will illuminate with a flickering flame effect.
- 2.Still Mode: Slide switch to "Still" position, the light will stay illuminated. Please note all LED's will not be illuminated in this setting.
- 3.Off Mode: Slide switch to the "Off" position, the light power is off.



#### **WARNING & NOTICE**

- 1.Do not look directly at the LED light, or it may damage your eyes.
- 2. Do not attempt to disassemble or remodel the product. Any changes can be dangerous and will void the warranty.
- 3. Pease keep the product away from the flammable items, or explosion or casual injuries may occur.
- 4. Please switch OFF the product when it is not in use for a long period of time.