





FADER CALIBRATION:


1 MOVE FADERS ALL THE WAY OUT.



2 PRESS AND HOLD (FADER) AND (REVERSE) BUTTONS UNTIL YOU HEAR A TONE FROM SPEAKER. RELEASE (FADER) AND (REVERSE).



3 PRESS START / STOP BUTTON ONCE.



4 MOVE FADERS TO THE INSIDE. THEN PRESS (START / STOP) BUTTON.

