



Vogue

Lite Stroller "Grey"
Model # 015262-314



**IMPORTANT:
RETAIN FOR FUTURE REFERENCE,
READ CAREFULLY**

Read all instructions before assembly and use of the stroller / pram.
Keep instructions for future use.

WARNING

BEFORE ASSEMBLING THIS STROLLER / PRAM READ AND UNDERSTAND THE INSTRUCTIONS.

To avoid injury or death:

Always apply the brakes whenever the stroller / pram is parked.

Do not leave children unattended.

Secure the child in the harness at all times.

Do not carry extra children or bags on this stroller / pram.

Make sure children are clear of any moving parts if you adjust the stroller / pram.

To avoid injury ensure that your child is kept away when folding and unfolding the stroller / pram.

Ensure that all locking devices are engaged before use.

Use the tether strap to stop the stroller / pram rolling away.

Do not use this bassinet once the child can sit up unaided.

 **Be aware that moving parts may cause injury if care is not taken.** 

KEEP INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

The weight of the child using the product should not exceed 20kgs.

The height of the child using the product should not exceed 96cm.

Fingers or parts of the body could be injured when the stroller / pram is being folded or unfolded. Please use caution when folding or unfolding the stroller / pram.

Always check that safety locks are engaged before placing a child in the stroller / pram.

Ensure your child is secured with a correctly adjusted safety harness.

DO NOT allow children to stand on the seat.

DO NOT hang bags or goods from the handle as this could cause the stroller / pram to tip over.

DO NOT place more than 5kgs in the basket or 1kg in the hood pocket (if supplied).

It is unsafe to use parts other than those approved by the manufacturer.

NEVER use with more than one child in the stroller / pram.

This stroller / pram has been designed for use on flat or gently sloped surfaces. Using this stroller / pram on uneven or higher sloped surfaces may cause the stroller / pram to become unstable and tip over.

Regularly inspect all parts and locking devices, promptly replace worn out or broken parts.

Care must be taken if the stroller / pram is used on stairs or escalators. Always remove the child from the stroller / pram before going up or down stairs and escalators.

To prevent the risk of the stroller / pram catching fire, **DO NOT** park it near an open fire, heater or barbecue.

DO NOT make any changes or alterations to this product, unless through an approved service agent.

To avoid the risk of suffocation, keep all plastic packaging materials out of reach of children.

NEVER leave safety harness connected when not fitted to a child in the stroller / pram as this may create loops that could cause a strangulation hazard.

Ensure the storage latch is fully engaged when lifting or carrying the stroller / pram.

Care must be taken when lifting or carrying the stroller / pram.

Congratulations on your purchase of the **Vogue Lite Stroller "Grey"**

This product has been designed and developed with safety, comfort and functionality in mind. Please take the time to read this manual carefully before using this product and keep it in a safe place for future reference.

Contents

Assembly contents list

Assembly / Operating instructions

How to care for your **Vogue Lite Stroller**











Due to variations in the style and design of our products, the photographs and illustrations shown in this instruction manual are generic, therefore product fabrics, colour and design may vary from images shown. CNP Brands reserves the right to alter product specifications without notice as a result of our ongoing policy of product improvement.

Check what you have received...

You have received **1 box**. Please check the contents of the box against the list below. If anything is missing, please contact Customer Service.

In Australia, contact **CNP Brands on 1300 667 137**, in New Zealand contact **Wainhouse Distribution on 0800 567 5000**.

Supplied loose in box:

Carry Cot/Seat Unit		x 1	Boot Cover		x 1
Frame		x 1	Canopy		x 1
Rear Wheels		x 2	Bumper Bar		x 1
Front Wheels		x 2	Rain Cover		x 1

There are no accessories recommended for use with this Childcare Vogue Lite Stroller.

To unfold Stroller...

1

1a. Disengage uplock to release the stroller frame.



2

2a. Lift stroller handle upward until the stroller opens fully and 'clicks' into position.



To assemble Rear Wheels...

1

1a. Insert rear wheel into the rear wheel housing until wheel 'clicks' into position.

1b. Repeat for other rear wheel.



To remove Rear Wheels...

- 1 1a. Push in and hold the quick release tab.



- 2 2a. Remove rear wheel from the rear wheel housing.



To use Rear Brakes...

- 1 1a. To lock brakes, push down on the brake lever, located on the rear wheel axle.



- 2 2a. To unlock brakes, lift the brake lever.



⚠ WARNING ⚠

Always apply brakes when parking stroller.

To assemble Front Wheels...

1

- 1a. Insert front wheel into the front wheel housing until wheel **'clicks'** into position.
- 1b. Repeat for other front wheel.



To operate Swivel Function...

1

- 1a. To lock swivel function, push lever downward.



2

- 2a. To unlock swivel function, push lever upward.



⚠ WARNING ⚠

On unmade or uneven surfaces, swivel wheels must be locked.

To remove Front Wheels...

1

1a. Push in and hold the quick release tab.



2

2a. Remove front wheel from the front wheel housing.



To prepare Seat...

1

1a. Turn bassinet upside down. Lift rear bar.



2


2a. Wrap and secure Velcro fabric around the rear bar.




To assemble Bassinet...

NOTE: This step is easier to complete before attaching seat to the frame.

- 1** 1a. Completely loosen the seat adjuster straps under the backrest.



- 2** 2a. Unclasp the clips at the legrest and foot of the bassinet, located on the underside of the seat.



- 3** 3a. Adjust the seat to a parallel position.



⚠ WARNING ⚠


Bassinet cannot stand alone.

Do not use this bassinet once the child can sit up unaided.

Bassinet mode should not be used once the child has reached the maximum bassinet weight of 9kg.

To attach Seat...

- 1
 - 1a. Slide both sides of the seat into the frame housings until both sides **'click'** into position.
 - 1b. Pull up on seat to confirm it is secured correctly.



To adjust Seat Position...

- 1
 - 1a. This stroller has 4 lockable seat positions.
 - 1b. Push both seat adjustment buttons simultaneously and move the seat upward or downward to desired position.



To attach Bumper Bar...

- 1
 - 1a. Insert bumper bar into the bumper bar openings on each side of the seat assembly.
 - 1b. Bumper bar will **'click'** when locked in. Ensure bumper bar is secured correctly before use.



⚠ WARNING ⚠

Never use the bumper bar to carry the carry cot.

To remove Bumper Bar...

- 1
 - 1a. Push the buttons on the underside of the bumper bar.
 - 1b. Pull bumper bar away from the seat.



To assemble / disassemble Canopy...

- 1
 - 1a. To assemble the canopy, attach the canopy clips to each side of the stroller frame.
 - 1b. Push the clips onto the stroller frame until they 'click' into position.



- 2
 - 2a. Attach the press studs on the canopy to the press studs on the side of the seat frame.
 - 2b. Attach the press stud on the back of the canopy to the press stud on the back of the seat frame.



To operate Canopy Functions...

- 1
 - 1a. Pull the canopy forward or backward.
 - 1b. Pull out the sunvisor from the inside of the hood.



To operate Canopy Functions continued...

2

- 2a. To open the mesh extension, unzip the zip around the bottom of the canopy.
- 2b. Secure flap with the toggle and elastic strap.




CAUTION: Canopy must be fully closed before folding the stroller.

To attach Boot Cover...

1

- 1a. Wrap the boot cover around the bottom end of the seat frame.
- 1b. Attach both side wing press studs to the press studs on the outside of the seat.
- 1c. Wrap the boot cover up and around the bumper bar.
- 1d. Secure with the two press studs.




! WARNING !

Always remove boot cover before folding the stroller.

To use Tether Strap...

1

- 1a. Feed your hand through the tether strap loop as shown in image.



NOTE: Tether strap must be used at all times.

To convert to Stroller...

NOTE: This step is easier to complete before attaching seat to the frame.


- 1** 1a. Push the seat adjustment buttons on the stroller frame. Move the seat upright until seat is locked into position.



- 2** 2a. Tighten backrest adjuster to the desired upright position.



- 3** 3a. Buckle the straps under the legrest and foot of the seat assembly.



To adjust Backrest...

This stroller has an adjustable backrest. The upright position on the backrest is not suitable for use with children less than six months old.

For use with newborns (0-6 months), the seat must be fully reclined. The backrest should only be adjusted to a more upright position as the child grows older and is able to support their head without assistance.

- 1** 1a. To recline the seat, press and pull adjuster in a downward motion and lower to desired position.



To adjust Backrest continued...

- 2** 2a. To incline the seat, hold both adjustment straps and pull outward to desired position.

! WARNING !

Do not adjust the backrest whilst the child is in the stroller.



To assemble Rain Cover...

- 1** 1a. Fully open rain cover.
1b. Cover stroller completely.



Restraints - Harness...

1 To secure the child in the harness, place left hand buckle prong (b) on top of (a).

2 Hold both left hand buckle prongs (a) and (b) together and insert it into buckle housing (e) until it snaps into position.

3 Repeat previous steps for right hand buckle prongs (c) and (d).

4 Once all attached, carefully adjust the harness straps by pulling each slider (f) until the desired fit is achieved in the lap, shoulder and crotch straps.

5 To release the buckles, squeeze the top and bottom prongs (a) and (b), (c) and (d) together until harness disengages.



(a), (b): Left hand buckle prongs
 (c), (d): Right hand buckle prongs
 (e): Buckle housing
 (f): Strap adjustment sliders

! WARNING !


USE THIS HARNESS AT ALL TIMES

CAUTION: Always adjust the harness when changing the seating position of the child.

To adjust Waist Strap...

1

- 1a. To loosen waist strap, push up both top and bottom straps through buckle.
- 1b. To place waist strap in desired position, slide the bottom strap into position then pull the top strap and tighten into position.



! WARNING !

USE THIS HARNESS AT ALL TIMES

To fold Stroller...

1

- 1a. Ensure that the stroller seat recline is in the fully upright position.
- 1b. Ensure the canopy is pushed all the way back.
- 1c. Slide the handle lever to the left, whilst holding in the handle button.




2

- 2a. Push handle down towards the back wheels.



3

- 3a. Secure the folded stroller with the upfold lock.
- 3b. Use the first loop when stroller is folded in seat mode.
- 3c. Use the second loop when stroller is folded in bassinet mode.



NOTE: Remove seat assembly from the frame when folding for a smaller fold.



Cleaning

To ensure the long-lasting use of your stroller, dry it with a soft absorbent cloth after use in rainy weather. Use a damp cloth to clean the frame. Do not use abrasive cleaners. After using your stroller on the beach, clean the frame and wheels thoroughly with water to remove the sand and salt. Allow it to dry thoroughly. Removable and non removable fabric covers and trims maybe cleaned using a damp cloth with soap or mild detergent. Allow it to dry completely before folding or storing it away. Do not dry clean, or use bleach on fabrics or trims. Do not machine wash, tumble or spin dry, unless the care labelling on the product permits these methods.

Maintenance

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required. To maintain the safety of your stroller, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by **CNP Brands**.

If you have any difficulties in assembling the stroller, please contact our Service Department.

In Australia, contact **CNP Brands on 1300 667 137**, in New Zealand contact **Wainhouse Distribution on 0800 567 5000**.



CNP BRANDS

CHILDCARE NURSERY PRODUCTS | EST. 1899

About CNP Brands

Currently, **CNP Brands** boasts one of the most diverse brand portfolios with a combination of company owned brands and distribution agreements. These include distribution lines for **Evenflo, Good Baby, Lascal, Maclaren, Project Nursery, Summer Infant and Yookidoo.**

Our own brands, including **Childcare**, have gone from strength to strength in recent years. **Childcare**, and our premium brand **bebe care**, demonstrate our commitment to quality and continuing investment in product development.



NOTES



A series of horizontal dotted lines for writing notes.



CNP BRANDS

CHILDCARE NURSERY PRODUCTS | EST. 1899



Distributed in Australia by CNP Brands
Customer Service 1300 667 137

W: www.cnpbrands.com.au
E: info@cnpbrands.com.au
F: www.facebook.com/CNPBrands
I: @cnp_baby

Distributed in New Zealand by Wainhouse
Distribution
2-6 Argyle St, Morningside,
PO Box 41-014,
St Lukes, Auckland, New Zealand
Customer Service: 0800 567 5000

E: helpline@wainhousedist.co.nz

