

TALKING HEARTS VOICE RECORDER



V1.0



Talking Hearts are high quality voice recorders that allow you to record and playback speech, music, and sound effects. Each heart has a recording time of up to 2 minutes, (120 seconds).

Please read the following instructions carefully and refer to the diagrams overleaf.


How to record a message

Turn the heart upside down and move the ON-OFF Switch to the ON position. Move the mode switch to the 'A' position, (Record).


Squeeze the heart once and release. The red light will illuminate and you will hear a 'beep' sound to indicate recording has begun.

Speak clearly into the microphone at a distance of approximately 15cm.

When you have finished recording squeeze the heart once and release. You will hear two 'beeps' to indicate that recording is complete.



How to insert and remove batteries



TALKING HEARTS VOICE RECORDER

NOTE:

The red light will remain on when recording and turn off when recording is complete.

You can only record one single 2 minute message. If you make a mistake during the recording you can re-record as many times as you wish, but the new recorded message will replace the previous one.

How to playback a message

Move the Mode Switch to the 'B' position, (Play). Squeeze the heart once and release. If you wish to stop the playback at any time squeeze again.

Volume control and sound quality

You can adjust the playback volume by changing the distance you speak from the microphone.

It is recommended that you record your message in a quiet place away from any background noise. Recording close to electronic equipment or air conditioning can affect recording quality.

How to protect your message

You can protect your message from accidental erasure. Locate the LOCK switch hidden inside the battery compartment, (see diagram overleaf). To disable recording, move the switch to the right position.

When recording is disabled with the LOCK switch, the heart will only be able to playback. Therefore, if you have recorded a precious message that you wish to protect, it is recommended that you keep the switch in the LOCK position at all times.

NOTE:

Your recorded message will be stored and preserved forever, even if the batteries are depleted or replaced.

Product Code:

TH1-120-PUR



Safety Information

1. Please keep the packaging and this document for future reference, it contains important information.
2. Not suitable for children under 3 years of age.
3. Do not mix different types of batteries.
4. Do not mix old and new batteries.
5. Batteries must be fitted with the correct polarity.
6. Exhausted batteries must be removed from the battery compartment.
7. Non-rechargeable batteries are not to be charged.
8. Rechargeable batteries must be removed from the battery compartment before being charged.
9. Rechargeable batteries must only be charged under adult supervision.
10. The power supply terminals must not be short-circuited.



Talking Products Ltd
Unit C8 The Premier Centre
Abbey Park Industrial Estate
Romsey, Hampshire
SO51 9DG, England

Tel: +44 (0) 1794 278327

Email: sales@TalkingProducts.com

www.TalkingProducts.com