Grocery Store Check Out Counter

Assembly & User Instructions - Please keep for future reference

59535





Important

Age: 3 years +



Safety Information

Important - Please read these instructions fully before assembly or use

General safety



 Warning! Not suitable for children under 36 months due to small parts - choking hazard.




• Caution! Product should be used only for purpose for which it was designed. Children should not stand or climb on product.

- · Toy to be assembled by a responsible adult.
- · Remove all packaging before giving to your child.
- Young children in play are unaware of potential hazards and dangers, therefore responsible adult supervision is essential.


Parts


Please check that you have all the parts and fittings listed below



Hardware


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.







Step 2


Step 3






Step 4







Step 6


Step 7





Step 8







Step 10


Step 11








Step 13





Accessories included



Care and Maintenance

General

- · Wipe clean with a damp cloth only.
- Important: Check the product and fixings regularly to ensure no parts are damaged, loose, lost or broken.

 The product should be regularly inspected by an adult for broken or damaged parts.

Warning! Not suitable for children under 36 months. Choking hazard. Small parts.



Playtime by Eimmie 20801 Miles Road UNIT D North Randall, OH 44128

Made in China

CUSTOMER SERVICE

Missing or damaged parts?
Please contact us at 1-855-346-6436 or e-mail
info@playtimebyeimmie.com