


HYBRID STRAP - Adjustment



1. Removal

Please ensure that pins are installed from different directions above and below the watch case. Only the links marked with an arrow can be changed. For removal push the pin in direction of the arrows. Put the open end out **first**.

Tension-Pin:

