Function	Operation
Power On/Off	Plug/Unplug the product into/out from your car charger port
Display car battery voltage	Plug the product into your car charger port, the display will show car battery voltage for 1 sec
Frequency Up/Down	Long press the "MFB" button, then press the "Next"/"Previous" button or rotate the "MFB" to add/reduce frequency
Play/Pause/Answer/Hang up	Press the "MFB" once
Reject a call	Long press the "MFB" for about 2 seconds
Redial the last number	Press the "MFB" twice
Volume Up/Down	Rotate the "MFB"
Next/Previous Song	Press the "Next"/"Previous" button once
Light mode	Press the "Light switch" button
Switch music source	Long press the "Next" button to switch from Bluetooth mode or USB Flash drive/Micro SD card mode music, when switch to Bluetooth mode, press "MFB" once to start the music.
Activate phone voice control	In Bluetooth mode, long press the "Previous" button

INSTRUCTION


- 1. Plug the product into your car charger port, the flashes means it is in pairing mode.
- 2. Turn on the Bluetooth function of your phone, search for Bluetooth devices and connect "CAPDASE", No password asked when paring.
- If Paring is successful, the display will stop flash and show FM frequency.

Auto-connect: The product will auto-connect the last connected phone when turned on next time. (Please turn on the Bluetooth function of your phone before turn on the product)

- 3. Adjust the car FM radio to a blank frequency from 87.5MHz to 108.0MHz, for example: 89.1
- 4. Adjust the product into the same frequency with the car FM radio. (Long press the "MFB" button, then rotate the "MFB" or press the "Previous"/"Next" button to add/reduce frequency.)
- 5. Open the music player/navigation of your phone, now it can transmit the phone calls, music or navigation to car stereo system.
- Tip: Turn the phone volume and transmitter volume into max level first, then tune your car volume to appropriate level, to get the best sound quality.
- You can also insert the USB Flash drive/Micro SD card into the product, it will automatically detect and play the MP3/MA/FLAC format music.

YIN-00615

USER MANUAL




IMPORTANT

- SAVE THIS INSTRUCTION This manual contains important safety and operating instructions for the product.
- 2. Before using the product, read all instructions and cautionary markings on Vehicle Battery Adapters.
- 3. For the best audio quality, turn the volume of your phone and FM transmitter to the maximum level, and then adjust the car volume.
- 4. If the noise is too loud, try another blank FM station.
- 5. The signal of any FM transmitter can sometimes be interfered with by the surrounding radio or a similar frequency signal, thus causing noise. This is normal.
- To prevent your car battery from being drained, unplug the product after turning off the car.
- 7. Do not expose the product to rain, moisture, or snow.
- 8. Do not disassemble the product; incorrect reassembly may result in the risk of electric shock or fire.
- 9. To reduce the risk of electric shock, unplug the product before attempting any maintenance. Turning off controls will not reduce this risk.

CAR CHARGER KIT-POWER KIT-BFP2Q3

使用手冊



操作說明

- 1. 將產品插入汽車點煙口。
- 2. 插入後, 將自動開機, 顯示幕會顯示汽車電壓值, 然後閃爍表示產品等待配對中。
- 3. 打開智能設備的藍牙功能, 搜索藍牙設備並選擇"CAPDASE"配對。(無需密碼)
- 4. 如果配對成功. 顯示幕將停止閃爍並顯示FM頻率。
- 5. 將汽車FM收音機調到空白的FM頻道。(頻道由87.5MHz 至108.0MHz, 例如:89.1)
- 6. 將產品調到和汽車FM收音機相同的頻道。
- 7. 打開智能設備的音樂播放機/導航軟體, 就可以將音樂, 導航或電話傳輸到汽車音響系統播放。 藍牙自動回連!產品下次開機時, 將自動連接到最後配對的設備。

(保證先打開智能設備的藍牙,然後再將產品開機。)

注意

- 1. 為獲得最佳音質, 請將智能設備和此產品的音量調至最高水準。
- 2. 任何MP3播放機的信號有時會被周圍的無線電或類似的頻率信號干擾, 從而產生雜訊, 這是正常的現象。
- 3. 如果噪音太大, 請確認此產品的頻道和汽車的頻道是否一致, 或者嘗試另一個空白FM頻道。

撥打/接聽電話

通過藍牙成功連接到手機後,可以通過此產品撥打或接聽電話。

- 1. 重撥最後一個號碼:按兩下多功能按鍵。
- 2. 拒絕來電:長按多功能按鍵約2秒鐘。
- 3. 接聽電話:按多功能按鍵一次。
- 4. 掛斷電話:按多功能按鍵一次。

音樂播放/暫停

- 1. 播放/暫停:按多功能按鍵一次。
- 2. 下一曲:按"下一曲"按鈕。
- 3. 上一曲:按"上一曲"按鈕。播放USB Flash Drive或TF/Micro SD卡裡面的音樂:

燈光切換

按"燈光切換按鍵"切換自己喜歡的燈光顏色。

音源切換

此產品默認播放最後連接的音源,並記憶最後一首開頭的位置,下次開機會繼續播放。

如果藍牙, USB Flash Drive或TF/Micro SD卡全部連接了, 長按 "下一曲" 按鈕約4秒鐘即可切換音源。

切換到藍牙音樂時, 需要按播放按鈕才能開始播放音樂。