

# eLite FLOW INSTRUCTIONS

The eLite FLOW Chip comes set with 9 specially designed modes right out of the box and allows users to choose from 20 different color selections to create any type of 1, 2, or 3 color strobe they desire.

## Features to Customize:

- 1 Master Color Set (1-3 colors)

**Default Modes + Colors:** The light will come pre-programmed with a **RedGreenBlue** color combination already selected across all of its 9 modes:



## Normal Operation:

1. Click the button to turn the light on and cycle through each of your 9 modes. Your light will go back to the 2nd mode (Hyper Strobe) mode after cycling through all 9 modes.
2. Turn light off by holding the button down in any mode. Release the button when the light turns off.
3. To turn the light back on, click the button and the light will turn back on in Mode 1 (Flow/Demo).

**\*Please Note:** We made the Flow/Demo mode the default first option as an added convenience for spinners who want to hop right into their performances. Since this would get visually confusing when trying to change modes mid-lightshow, once you advance to the 2nd mode (Hyper Strobe) the chip becomes an 8 mode light, removing the demo mode from the options until you turn off the light and back on again.

## Programming Color Sets:

The eLite FLOW gives you the ability to program a unique 1-3 color set that will change the look of all the modes on your light:

1. From the OFF position, hold down the light's button and let go when you see the **orange** flashes.
2. Scroll through the color selection by clicking through one at a time.
3. When you find a color you want to select, hold down the button for half a second and let go when the light turns off.
4. After each selected color, your light will quickly flash your previous selections one color at a time. After 3 colors are selected your light will quickly turn off and back on with it's newly selected colors.

## Master Reset:

To reset the light to factory defaults.

1. When the light is off, hold the button down until you see 10 **white** flashes and then let go of the button. Your eLite FLOW will now be reset to the factory default **RGB** settings.

## Programmable Colors:



Video Tutorial Available at: <http://www.YouTube.com/AmazingLights>